


HP ProLiant DL160se G6 Server

Maintenance and Service Guide



Legal notices

© Copyright 2010 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Intel, Xeon, and Intel Core are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Contents

| | |
|---|-----|
| Customer self repair | 5 |
| Parts only warranty service..... | 5 |
| Illustrated parts catalog | 16 |
| Mechanical components / 2 or 4 3.5" hot-plug HDD model..... | 16 |
| Mechanical components / 4 3.5" HDD non-hot-plug model..... | 17 |
| Mechanical components / 8 2.5" hot-plug HDD model..... | 18 |
| System components / 2 3.5" HDD hot-plug model | 22 |
| System components / 4 3.5" HDD hot-plug model | 24 |
| System components / 4 3.5" HDD non-hot-plug model | 26 |
| System components / 8 2.5" HDD hot-plug model | 28 |
| HP contact information | 31 |
| Before you contact HP | 31 |
| Removal and replacement procedures | 33 |
| Hardware configuration tools | 33 |
| Hardware configuration information..... | 33 |
| Electrostatic discharge information | 33 |
| Pre-installation procedure | 34 |
| Post-installation instructions..... | 34 |
| Server warnings and cautions..... | 35 |
| HP Trusted Platform Module..... | 35 |
| Symbols on equipment..... | 35 |
| Powering down the server..... | 36 |
| System cover | 37 |
| Top cover..... | 37 |
| Drives..... | 38 |
| Cable management..... | 38 |
| Cable connections | 39 |
| Drive bay configuration | 41 |
| Optical disc drive Bay | 45 |
| Hard drives | 47 |
| SAS/SATA HDD backplane | 55 |
| System board configuration..... | 62 |
| Processor | 62 |
| Memory..... | 68 |
| DIMM identification..... | 71 |
| PCI expansion card..... | 72 |
| Dedicated management port (Optional) | 82 |
| System battery | 84 |
| BBWC (Optional)..... | 86 |
| System board removal and replacement procedure | 88 |
| Power supply unit (PSU) | 90 |
| System fan | 94 |
| Connectors, switches, and LEDs | 96 |
| Connectors and components | 96 |
| Front panel components..... | 96 |
| Rear panel components | 100 |

| | |
|---|-----|
| System board components..... | 102 |
| Jumpers | 103 |
| LED indicators | 104 |
| Front panel LED indicators..... | 104 |
| Optical disk drive activity LED indicator | 105 |
| Hard Drive LED indicators | 106 |
| Rear panel LED indicators | 107 |
| System board LED indicator..... | 108 |
| Diagnostic tools and setup utilities | 109 |
| BIOS software | 109 |
| BIOS Setup Utility | 109 |
| Accessing the BIOS Setup Utility | 109 |
| Navigating through the Setup Utility | 110 |
| Setup Utility menu bar | 111 |
| BIOS update | 117 |
| Clear CMOS..... | 117 |
| Power-On Self-Test (POST)..... | 117 |
| POST error indicators | 118 |
| POST error descriptions | 118 |
| POST related troubleshooting..... | 119 |
| SETSYS utility..... | 120 |
| Physical and operating specifications | 121 |
| System unit..... | 121 |
| Index | 126 |

Customer self repair

HP products are designed with many Customer Self Repair (CSR) parts to minimize repair time and allow for greater flexibility in performing defective parts replacement. If during the diagnosis period HP (or HP service providers or service partners) identifies that the repair can be accomplished by the use of a CSR part, HP will ship that part directly to you for replacement. There are two categories of CSR parts:

- **Mandatory**—Parts for which customer self repair is mandatory. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.
- **No**—Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

NOTE: Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

Based on availability and where geography permits, CSR parts will be shipped for next business day delivery. Same day or four-hour delivery may be offered at an additional charge where geography permits. If assistance is required, you can call the HP Technical Support Center and a technician will help you over the telephone. HP specifies in the materials shipped with a replacement CSR part whether a defective part must be returned to HP. In cases where it is required to return the defective part to HP, you must ship the defective part back to HP within a defined period of time, normally five (5) business days. The defective part must be returned with the associated documentation in the provided shipping material. Failure to return the defective part may result in HP billing you for the replacement. With a customer self repair, HP will pay all shipping and part return costs and determine the courier/carrier to be used.

For more information about HP's Customer Self Repair program, contact your local service provider. For the North American program, refer to the HP website (<http://www.hp.com/go/selfrepair>).

Parts only warranty service

Your HP Limited Warranty may include a parts only warranty service. Under the terms of parts only warranty service, HP will provide replacement parts free of charge.

For parts only warranty service, CSR part replacement is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

Réparation par le client (CSR)

Les produits HP comportent de nombreuses pièces CSR (Customer Self Repair = réparation par le client) afin de minimiser les délais de réparation et faciliter le remplacement des pièces défectueuses. Si pendant la période de diagnostic, HP (ou ses partenaires ou mainteneurs agréés) détermine que la réparation peut être effectuée à l'aide d'une pièce CSR, HP vous l'envoie directement. Il existe deux catégories de pièces CSR:

- **Obligatoire**—Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.
- **Facultatif**—Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

REMARQUE: Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

Les pièces CSR sont livrées le jour ouvré suivant, dans la limite des stocks disponibles et selon votre situation géographique. Si votre situation géographique le permet et que vous demandez une livraison le jour même ou dans les 4 heures, celle-ci vous sera facturée. Pour bénéficier d'une assistance téléphonique, appelez le Centre d'assistance technique HP. Dans les documents envoyés avec la pièce de rechange CSR, HP précise s'il est nécessaire de lui retourner la pièce défectueuse. Si c'est le cas, vous devez le faire dans le délai indiqué, généralement cinq (5) jours ouvrés. La pièce et sa documentation doivent être retournées dans l'emballage fourni. Si vous ne retournez pas la pièce défectueuse, HP se réserve le droit de vous facturer les coûts de remplacement. Dans le cas d'une pièce CSR, HP supporte l'ensemble des frais d'expédition et de retour, et détermine la société de courses ou le transporteur à utiliser.

Pour plus d'informations sur le programme CSR de HP, contactez votre Mainteneur Agréé local. Pour plus d'informations sur ce programme en Amérique du Nord, consultez le site Web HP (<http://www.hp.com/go/selfrepair>).

Service de garantie "pièces seules"

Votre garantie limitée HP peut inclure un service de garantie "pièces seules". Dans ce cas, les pièces de rechange fournies par HP ne sont pas facturées.

Dans le cadre de ce service, la réparation des pièces CSR par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

Riparazione da parte del cliente

Per abbreviare i tempi di riparazione e garantire una maggiore flessibilità nella sostituzione di parti difettose, i prodotti HP sono realizzati con numerosi componenti che possono essere riparati direttamente dal cliente (CSR, Customer Self Repair). Se in fase di diagnostica HP (o un centro di servizi o di assistenza HP) identifica il guasto come riparabile mediante un ricambio CSR, HP lo spedisce direttamente al cliente per la sostituzione. Vi sono due categorie di parti CSR:

- **Obbligatorie**—Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.
- **Opzionali**—Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto.

NOTA: alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

In base alla disponibilità e alla località geografica, le parti CSR vengono spedite con consegna entro il giorno lavorativo seguente. La consegna nel giorno stesso o entro quattro ore è offerta con un supplemento di costo solo in alcune zone. In caso di necessità si può richiedere l'assistenza telefonica di un addetto del centro di supporto tecnico HP. Nel materiale fornito con una parte di ricambio CSR, HP specifica se il cliente deve restituire dei componenti. Qualora sia richiesta la resa ad HP del componente difettoso, lo si deve spedire ad HP entro un determinato periodo di tempo, generalmente cinque (5) giorni lavorativi. Il componente difettoso deve essere restituito con la documentazione associata nell'imballo di spedizione fornito. La mancata restituzione del componente può comportare la fatturazione del ricambio da parte di HP. Nel caso di riparazione da parte del cliente, HP sostiene tutte le spese di spedizione e resa e sceglie il corriere/vettore da utilizzare.

Per ulteriori informazioni sul programma CSR di HP contattare il centro di assistenza di zona. Per il programma in Nord America fare riferimento al sito Web HP (<http://www.hp.com/go/selfrepair>).

Servizio di garanzia per i soli componenti

La garanzia limitata HP può includere un servizio di garanzia per i soli componenti. Nei termini di garanzia del servizio per i soli componenti, HP fornirà gratuitamente le parti di ricambio.

Per il servizio di garanzia per i soli componenti è obbligatoria la formula CSR che prevede la riparazione da parte del cliente. Se il cliente invece richiede la sostituzione ad HP, dovrà sostenere le spese di spedizione e di manodopera per il servizio.

Customer self repair

HP Produkte enthalten viele CSR-Teile (Customer Self Repair), um Reparaturzeiten zu minimieren und höhere Flexibilität beim Austausch defekter Bauteile zu ermöglichen. Wenn HP (oder ein HP Servicepartner) bei der Diagnose feststellt, dass das Produkt mithilfe eines CSR-Teils repariert werden kann, sendet Ihnen HP dieses Bauteil zum Austausch direkt zu. CSR-Teile werden in zwei Kategorien unterteilt:

- **Zwingend**—Teile, für die das Customer Self Repair-Verfahren zwingend vorgegeben ist. Wenn Sie den Austausch dieser Teile von HP vornehmen lassen, werden Ihnen die Anfahrt- und Arbeitskosten für diesen Service berechnet.
- **Optional**—Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

HINWEIS: Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

CSR-Teile werden abhängig von der Verfügbarkeit und vom Lieferziel am folgenden Geschäftstag geliefert. Für bestimmte Standorte ist eine Lieferung am selben Tag oder innerhalb von vier Stunden gegen einen Aufpreis verfügbar. Wenn Sie Hilfe benötigen, können Sie das HP technische Support Center anrufen und sich von einem Mitarbeiter per Telefon helfen lassen. Den Materialien, die mit einem CSR-Ersatzteil geliefert werden, können Sie entnehmen, ob das defekte Teil an HP zurückgeschickt werden muss. Wenn es erforderlich ist, das defekte Teil an HP zurückzuschicken, müssen Sie dies innerhalb eines vorgegebenen Zeitraums tun, in der Regel innerhalb von fünf (5) Geschäftstagen. Das defekte Teil muss mit der zugehörigen Dokumentation in der Verpackung zurückgeschickt werden, die im Lieferumfang enthalten ist. Wenn Sie das defekte Teil nicht zurückschicken, kann HP Ihnen das Ersatzteil in Rechnung stellen. Im Falle von Customer Self Repair kommt HP für alle Kosten für die Lieferung und Rücksendung auf und bestimmt den Kurier-/Frachtdienst.

Weitere Informationen über das HP Customer Self Repair Programm erhalten Sie von Ihrem Servicepartner vor Ort. Informationen über das CSR-Programm in Nordamerika finden Sie auf der HP Website unter (<http://www.hp.com/go/selfrepair>).

Parts-only warranty service (Garantieservice ausschließlich für Teile)

Ihre HP Garantie umfasst möglicherweise einen Parts-only Warranty Service (Garantieservice ausschließlich für Teile). Gemäß den Bestimmungen des Parts-only Warranty Service stellt HP Ersatzteile kostenlos zur Verfügung.

Für den Parts-only Warranty Service ist das CSR-Verfahren zwingend vorgegeben. Wenn Sie den Austausch dieser Teile von HP vornehmen lassen, werden Ihnen die Anfahrt- und Arbeitskosten für diesen Service berechnet

Reparaciones del propio cliente

Los productos de HP incluyen muchos componentes que el propio usuario puede reemplazar (*Customer Self Repair*, CSR) para minimizar el tiempo de reparación y ofrecer una mayor flexibilidad a la hora de realizar sustituciones de componentes defectuosos. Si, durante la fase de diagnóstico, HP (o los proveedores o socios de servicio de HP) identifica que una reparación puede llevarse a cabo mediante el uso de un componente CSR, HP le enviará dicho componente directamente para que realice su sustitución. Los componentes CSR se clasifican en dos categorías:

- **Obligatorio**—componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.
- **Opcional**—componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

NOTA: Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

Según la disponibilidad y la situación geográfica, los componentes CSR se enviarán para que lleguen a su destino al siguiente día laborable. Si la situación geográfica lo permite, se puede solicitar la entrega en el mismo día o en cuatro horas con un coste adicional. Si precisa asistencia técnica, puede llamar al Centro de asistencia técnica de HP y recibirá ayuda telefónica por parte de un técnico. Con el envío de materiales para la sustitución de componentes CSR, HP especificará si los componentes defectuosos deberán devolverse a HP. En aquellos casos en los que sea necesario devolver algún componente a HP, deberá hacerlo en el periodo de tiempo especificado, normalmente cinco días laborables. Los componentes defectuosos deberán devolverse con toda la documentación relacionada y con el embalaje de envío. Si no enviara el componente defectuoso requerido, HP podrá cobrarle por el de sustitución. En el caso de todas sustituciones que lleve a cabo el cliente, HP se hará cargo de todos los gastos de envío y devolución de componentes y escogerá la empresa de transporte que se utilice para dicho servicio.

Para obtener más información acerca del programa de Reparaciones del propio cliente de HP, póngase en contacto con su proveedor de servicios local. Si está interesado en el programa para Norteamérica, visite la página web de HP siguiente (<http://www.hp.com/go/selfrepair>).

Servicio de garantía exclusivo de componentes

La garantía limitada de HP puede que incluya un servicio de garantía exclusivo de componentes. Según las condiciones de este servicio exclusivo de componentes, HP le facilitará los componentes de repuesto sin cargo adicional alguno.

Para este servicio de garantía exclusivo de componentes, es obligatoria la sustitución de componentes por parte del usuario (CSR). Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

Customer self repair

Veel onderdelen in HP producten zijn door de klant zelf te repareren, waardoor de reparatieduur tot een minimum beperkt kan blijven en de flexibiliteit in het vervangen van defecte onderdelen groter is. Deze onderdelen worden CSR-onderdelen (Customer Self Repair) genoemd. Als HP (of een HP Service Partner) bij de diagnose vaststelt dat de reparatie kan worden uitgevoerd met een CSR-onderdeel, verzendt HP dat onderdeel rechtstreeks naar u, zodat u het defecte onderdeel daarmee kunt vervangen. Er zijn twee categorieën CSR-onderdelen:

- **Verplicht**—Onderdelen waarvoor reparatie door de klant verplicht is. Als u HP verzoekt deze onderdelen voor u te vervangen, worden u voor deze service reiskosten en arbeidsloon in rekening gebracht.
- **Optioneel**—Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garantieservice voor het product.

OPMERKING: Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

Afhankelijk van de leverbaarheid en de locatie worden CSR-onderdelen verzonden voor levering op de eerstvolgende werkdag. Levering op dezelfde dag of binnen vier uur kan tegen meerkosten worden aangeboden, indien dit mogelijk is gezien de locatie. Indien assistentie gewenst is, belt u een HP Service Partner om via de telefoon technische ondersteuning te ontvangen. HP vermeldt in de documentatie bij het vervangende CSR-onderdeel of het defecte onderdeel aan HP moet worden geretourneerd. Als het defecte onderdeel aan HP moet worden teruggezonden, moet u het defecte onderdeel binnen een bepaalde periode, gewoonlijk vijf (5) werkdagen, retourneren aan HP. Het defecte onderdeel moet met de bijbehorende documentatie worden geretourneerd in het meegeleverde verpakkingsmateriaal. Als u het defecte onderdeel niet terugzendt, kan HP u voor het vervangende onderdeel kosten in rekening brengen. Bij reparatie door de klant betaalt HP alle verzendkosten voor het vervangende en geretourneerde onderdeel en kiest HP zelf welke koerier/transportonderneming hiervoor wordt gebruikt.

Neem contact op met een Service Partner voor meer informatie over het Customer Self Repair programma van HP. Informatie over Service Partners vindt u op de HP website (<http://www.hp.com/go/selfrepair>).

Garantieservice "Parts Only"

Het is mogelijk dat de HP garantie alleen de garantieservice "Parts Only" omvat. Volgens de bepalingen van de Parts Only garantieservice zal HP kosteloos vervangende onderdelen ter beschikking stellen.

Voor de Parts Only garantieservice is vervanging door CSR-onderdelen verplicht. Als u HP verzoekt deze onderdelen voor u te vervangen, worden u voor deze service reiskosten en arbeidsloon in rekening gebracht.

Reparo feito pelo cliente

Os produtos da HP são projetados com muitas peças para reparo feito pelo cliente (CSR) de modo a minimizar o tempo de reparo e permitir maior flexibilidade na substituição de peças com defeito. Se, durante o período de diagnóstico, a HP (ou fornecedores/parceiros de serviço da HP) concluir que o reparo pode ser efetuado pelo uso de uma peça CSR, a peça de reposição será enviada diretamente ao cliente. Existem duas categorias de peças CSR:

- **Obrigatória**—Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.
- **Opcional**—Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

OBSERVAÇÃO: Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

Conforme a disponibilidade e o local geográfico, as peças CSR serão enviadas no primeiro dia útil após o pedido. Onde as condições geográficas permitirem, a entrega no mesmo dia ou em quatro horas pode ser feita mediante uma taxa adicional. Se precisar de auxílio, entre em contato com o Centro de suporte técnico da HP para que um técnico o ajude por telefone. A HP especifica nos materiais fornecidos com a peça CSR de reposição se a peça com defeito deve ser devolvida à HP. Nos casos em que isso for necessário, é preciso enviar a peça com defeito à HP dentro do período determinado, normalmente cinco (5) dias úteis. A peça com defeito deve ser enviada com a documentação correspondente no material de transporte fornecido. Caso não o faça, a HP poderá cobrar a reposição. Para as peças de reparo feito pelo cliente, a HP paga todas as despesas de transporte e de devolução da peça e determina a transportadora/serviço postal a ser utilizado.

Para obter mais informações sobre o programa de reparo feito pelo cliente da HP, entre em contato com o fornecedor de serviços local. Para o programa norte-americano, visite o site da HP (<http://www.hp.com/go/selfrepair>).

Serviço de garantia apenas para peças

A garantia limitada da HP pode incluir um serviço de garantia apenas para peças. Segundo os termos do serviço de garantia apenas para peças, a HP fornece as peças de reposição sem cobrar nenhuma taxa.

No caso desse serviço, a substituição de peças CSR é obrigatória. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

顧客自己修理保証サービス

修理時間を短縮し、故障部品の交換における高い柔軟性を確保するために、HP製品には多数の顧客自己修理（CSR）部品があります。診断の際に、CSR部品を使用すれば修理ができるとHP（HPまたはHP正規保守代理店）が判断した場合、HPはその部品を直接、お客様に発送し、お客様に交換していただきます。CSR部品には以下の2通りがあります。

- 必須-顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。
- 任意-顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、別途費用を負担していただくことなく保証サービスを受けることができます。

注：HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

部品供給が可能な場合、地域によっては、CSR部品を翌営業日に届くように発送します。また、地域によっては、追加費用を負担いただくことにより同日または4時間以内に届くように発送することも可能な場合があります。サポートが必要なときは、HPの修理受付窓口に電話していただければ、技術者が電話でアドバイスします。交換用のCSR部品または同梱物には、故障部品をHPに返送する必要があるかどうかが表示されています。故障部品をHPに返送する必要がある場合は、指定期限内（通常は5営業日以内）に故障部品をHPに返送してください。故障部品を返送する場合は、届いた時の梱包箱に関連書類とともに入れてください。故障部品を返送しない場合、HPから部品費用が請求されます。顧客自己修理の際には、HPは送料および部品返送費を全額負担し、使用する宅配便会社や運送会社を指定します。

部品のみ保証サービス

HP保証サービスには、部品のみ保証サービスが適用される場合があります。このサービスでは、交換部品は無償で提供されます。

部品のみ保証サービスにおいては、CSR部品をお客様により交換作業していただくことが必須となります。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費はお客様の負担となります。

客户自行维修

HP 产品提供许多客户自行维修 (CSR) 部件，以尽可能缩短维修时间和在更换缺陷部件方面提供更大的灵活性。如果在诊断期间 HP（或 HP 服务提供商或服务合作伙伴）确定可以通过使用 CSR 部件完成维修，HP 将直接把该部件发送给您进行更换。有两类 CSR 部件：

- **强制性的** — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。
- **可选的** — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据为您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

注：某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

CSR 部件将在下一个工作日发运（取决于备货情况和允许的地理范围）。在允许的地理范围内，可在当天或四小时内发运，但要收取额外费用。如果需要帮助，您可以致电 HP 技术支持中心，将会有技术人员通过电话为您提供帮助。HP 会在随更换的 CSR 部件发运的材料中指明是否必须将有缺陷的部件返还给 HP。如果要求您将有缺陷的部件返还给 HP，那么您必须在规定期限内（通常是五 (5) 个工作日）将缺陷部件发给 HP。有缺陷的部件必须随所提供的发运材料中的相关文件一起返还。如果未能送还有缺陷的部件，HP 可能会要求您支付更换费用。客户自行维修时，HP 将承担所有相关运输和部件返回费用，并指定快递商/承运商。

有关 HP 客户自行维修计划的详细信息，请与您当地的服务提供商联系。有关北美地区的计划，请访问 HP 网站 (<http://www.hp.com/go/selfrepair>)。

仅部件保修服务

您的 HP 有限保修服务可能涉及仅部件保修服务。根据仅部件保修服务条款的规定，HP 将免费提供更换的部件。

仅部件保修服务要求进行 CSR 部件更换。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

客戶自行維修

HP 產品設計了許多「客戶自行維修」(CSR) 的零件以減少維修時間，並且使得更換瑕疵零件時能有更大的彈性。如果在診斷期間 HP (或 HP 服務供應商或維修夥伴) 辨認出此項維修工作可以藉由使用 CSR 零件來完成，則 HP 將直接寄送該零件給您作更換。CSR 零件分為兩種類別：

- **強制的** — 客戶自行維修所使用的零件是強制性的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。
- **選購的** — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。

備註：某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

基於材料取得及環境允許的情況下，CSR 零件將於下一個工作日以快遞寄送。在環境的允許下當天或四小時內送達，則可能需要額外的費用。若您需要協助，可致電「HP 技術支援中心」，會有一位技術人員透過電話來協助您。不論損壞的零件是否必須退回，HP 皆會在與 CSR 替換零件一起運送的材料中註明。若要將損壞的零件退回 HP，您必須在指定的一段時間內（通常為五 (5) 個工作天），將損壞的零件寄回 HP。損壞的零件必須與寄送資料中隨附的相關技術文件一併退還。如果無法退還損壞的零件，HP 可能要向您收取替換費用。針對客戶自行維修情形，HP 將負責所有運費及零件退還費用並指定使用何家快遞/貨運公司。

如需 HP 的「客戶自行維修」方案詳細資訊，請連絡您當地的服務供應商。至於北美方案，請參閱 HP 網站 (<http://www.hp.com/go/selfrepair>)。

僅限零件的保固服務

您的「HP 有限保固」可能包含僅限零件的保固服務。在僅限零件的保固服務情況下，HP 將免費提供替換零件。

針對僅限零件的保固服務，CSR 零件替換是強制性的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

고객 셀프 수리

HP 제품은 수리 시간을 최소화하고 결함이 있는 부품 교체 시 더욱 융통성을 발휘할 수 있도록 하기 위해 고객 셀프 수리(CSR) 부품을 다량 사용하여 설계되었습니다. 진단 기간 동안 HP(또는 HP 서비스 공급업체 또는 서비스 협력업체)에서 CSR 부품을 사용하여 수리가 가능하다고 판단되면 HP는 해당 부품을 바로 사용자에게 보내어 사용자가 교체할 수 있도록 합니다. CSR 부품에는 두 가지 종류가 있습니다.

- **고객 셀프 수리가 의무 사항인 필수 부품.** 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.
- **고객 셀프 수리가 선택 사항인 부품.** 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

참고: 일부 HP 부품은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 만족스러운 고객 보증을 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다. 이러한 부품들은 Illustrated Parts Catalog에 "No"라고 표시되어 있습니다.

CSR 부품은 재고 상태와 지리적 조건이 허용하는 경우 다음 영업일 납품이 가능하도록 배송이 이루어집니다. 지리적 조건이 허용하는 경우 추가 비용이 청구되는 조건으로 당일 또는 4시간 배송이 가능할 수도 있습니다. 도움이 필요하시면 HP 기술 지원 센터로 전화하십시오. 전문 기술자가 전화로 도움을 줄 것입니다. HP는 결함이 발생한 부품을 HP로 반환해야 하는지 여부를 CSR 교체 부품과 함께 배송된 자료에 지정합니다. 결함이 발생한 부품을 HP로 반환해야 하는 경우에는 지정된 기간 내(통상 영업일 기준 5일)에 HP로 반환해야 합니다. 이 때 결함이 발생한 부품은 제공된 포장 재료에 넣어 관련 설명서와 함께 반환해야 합니다. 결함이 발생한 부품을 반환하지 않는 경우 HP가 교체 부품에 대해 비용을 청구할 수 있습니다. 고객 셀프 수리의 경우, HP는 모든 운송 및 부품 반환 비용을 부담하며 이용할 운송업체 및 택배 서비스를 결정합니다.

HP 고객 셀프 수리 프로그램에 대한 자세한 내용은 가까운 서비스 제공업체에 문의하십시오. 북미 지역의 프로그램에 대해서는 HP 웹 사이트(<http://www.hp.com/go/selfrepair>)를 참조하십시오.

부품 제공 보증 서비스

HP 제한 보증에는 부품 제공 보증 서비스가 포함될 수 있습니다. 이러한 경우 HP는 부품 제공 보증 서비스의 조건에 따라 교체 부품만을 무료로 제공합니다.

부품 제공 보증 서비스 제공 시 CSR 부품 교체는 의무 사항입니다. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

Illustrated parts catalog

Mechanical components / 2 or 4 3.5" hot-plug HDD model




Table 1 Mechanical Components Spare Parts List / 2 or 4 3.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|--|-------------------|------------------------|
| 1 | Air baffle | 519710-001 | Mandatory ¹ |
| 2 | Power supply cage | 532473-001 | Mandatory ¹ |
| 3 | Rail kit | 573091-001 | Mandatory ¹ |
| 4 | Hard drive cage | 532114-001 | Mandatory ¹ |
| 5 | Hardware and Plastic Kit | 536390-001 | Mandatory ¹ |
| | BRKT FIXED PSU G6 SCR, 6-32 X .157,T10 SCR TT, 6-32x.160,SLT-T15 BRKT Rear I/O 1U G6 BLANK,HDD,SLIMLINE SFF HDD BLANK | | |
| 6 | Top cover | 507262-001 | Mandatory ¹ |

Mechanical components / 4 3.5" HDD non-hot-plug model




Table 2 Mechanical Components Spare Parts List / 4 3.5" HDD Non-hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|--|-------------------|------------------------|
| 1 | Air baffle | 519710-001 | Mandatory ¹ |
| 2 | Rail kit | 573091-001 | Mandatory ¹ |
| 3 | Hard drive cage | 532473-001 | Mandatory ¹ |
| 4 | Hardware and Plastic Kit | 536390-001 | Mandatory ¹ |
| | BRKT FIXED PSU G6 SCR, 6-32 X .157,T10 SCR TT, 6-32x.160,SLT-T15 BRKT Rear I/O 1U G6 BLANK,HDD,SLIMLINE SFF HDD BLANK | | |
| 5 | Top cover | 507262-001 | Mandatory ¹ |

Mechanical components / 8 2.5" hot-plug HDD model




Table 3 Mechanical Components Spare Parts List / 8 2.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|--|-------------------|------------------------|
| 1 | Air baffle | 519710-001 | Mandatory ¹ |
| 2 | Power supply cage | 532473-001 | Mandatory ¹ |
| 3 | Rail kit | 573091-001 | Mandatory ¹ |
| 4 | Hard drive cage | 532480-001 | Mandatory ¹ |
| 5 | Hardware and Plastic Kit | 536390-001 | Mandatory ¹ |
| | BRKT FIXED PSU G6 SCR, 6-32 X .157,T10 SCR TT, 6-32x.160,SLT-T15 BRKT Rear I/O 1U G6 BLANK,HDD,SLIMLINE SFF HDD BLANK | | |
| 6 | Top cover | 507262-001 | Mandatory ¹ |

¹Mandatory—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

²Optional—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

³No—Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

¹Mandatory: Obligatoire—Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

²Optional: Facultatif—Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

³No: Non—Certains pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

¹Mandatory: Obbligatorie—Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.

²Optional: Opzionali—Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto.

³No: Non CSR—Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

¹Mandatory: Zwingend—Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand- und Arbeitskosten für diesen Service berechnet.

²Optional: Optional—Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

³No: Kein—Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

¹Mandatory: Obligatorio—componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

²Optional: Opcional—componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

³No: No—Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

¹Mandatory: Verplicht—Onderdelen waarvoor Customer Self Repair verplicht is. Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening.

²Optional: Optioneel—Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garantieservice voor het product.

³No: Nee—Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

¹Mandatory: Obrigatória—Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

²Optional: Opcional—Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

³No: Nenhuma—Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

¹Mandatory : 必須 - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。

²Optional : 任意 - 顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、費用を負担していただくことなく保証サービスを受けることができます。

³No : 除外 - HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

¹Mandatory: 强制性的 — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

²Optional: 可选的 — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据为您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

³No: 否 — 某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

¹Mandatory: 強制的 — 客戶自行維修所使用的零件是強制的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

²Optional: 選購的 — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。

³No: 否 — 某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

¹ Mandatory: 필수 — 고객 셀프 수리가 의무 사항인 필수 부품. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

² Optional: 옵션 — 고객 셀프 수리가 선택 사항인 부품. 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

³ No: No — 고객 셀프 수리가 불가능하도록 설계된 HP 부품. 이 부품들은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 고객 보증을 만족시키기 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다.

System components / 2 3.5" HDD hot-plug model




Table 4 System Components Spare Parts List / 2 3.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|-----------------------------------|-------------------|------------------------|
| 1 | FH/FL riser card | | |
| | PCIex16 | 511808-001 | Mandatory ¹ |
| | PCIX | 511819-001 | Mandatory ¹ |
| 2 | LP PCIe16 riser card | 511809-001 | Mandatory ¹ |
| 3 | Non-hot-plug power supply (500 W) | 506247-001 | Mandatory ¹ |
| 4 | System board | 519709-001 | TBD |
| 5 | Memory modules | | |
| | Registered DIMMs (RDIMMs) | | |
| | DIMM, 2GB 2Rx8 PC3-10600R-9 | 501533-001 | Mandatory |
| | DIMM, 4GB 2Rx4 PC3-10600R-9 | 501534-001 | Mandatory |
| | DIMM, 4GB 4Rx8 PC3-8500R-7 LP | 501535-001 | Mandatory |
| | DIMM, 8GB 2Rx4 PC3-8500R-7 | 519201-001 | Mandatory |
| | Unregistered DIMMs (UDIMMs) | | |
| | DIMM, 1GB 1Rx8 PC3-10600E-9 | 501539-001 | Mandatory |
| | DIMM, 2GB 2Rx8 PC3-10600E-9 | 501540-001 | Mandatory |
| 6 | Processors, LGA 1366 Xeon™ Xeon | | |
| | PROC,Xeon EP 2.93 Ghz, 8M, 95W | 506012-001 | Mandatory ¹ |

Table 4 System Components Spare Parts List / 2 3.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|---|-------------------|------------------------|
| | PROC,Xeon EP 2.67 Ghz, 8M, 95W | 490070-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 80W | 490073-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.0 Ghz, 4M, 80W QC | 490074-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.53 Ghz, 8M, 80W | 490071-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 60W | 508567-001 | Mandatory ¹ |
| 7 | Processor heat sink | 511803-001 | Mandatory ¹ |
| 8 | Optical disc drive (optional) | | |
| | DRV,ODD, 9.5mm SATA DVD-ROM | 481430-001 | Mandatory ¹ |
| | DRV,ODD, 9.5mm SATA DVD-RW | 481431-001 | Mandatory ¹ |
| 9 | Hard drives | | |
| | 3.5" hot-plug LFF SAS hard drives with carriers | | |
| | 72 GB 15,000 rpm | 376594-001 | Mandatory |
| | 146 GB 15,000 rpm | 376595-001 | Mandatory |
| | 300 GB 15,000 rpm | 432146-001 | Mandatory |
| | 400 GB 10,000 rpm | 456896-001 | Mandatory |
| | 450 GB 15,000 rpm | 454274-001 | Mandatory |
| | 750 GB 7,200 rpm | 461288-001 | Mandatory |
| | 1 TB 7,200 rpm | 461289-001 | Mandatory |
| | 3.5" hot-plug SATA hard drives with carriers | | |
| | 160 GB 7,200 rpm, 1.5Gbps | 353043-001 | Mandatory |
| | 160 GB 7,200 rpm, 3.0Gbps | 483095-001 | Mandatory |
| | 250 GB 7,200 rpm, 1.5Gbps | 353044-001 | Mandatory |
| | 250 GB 7,200 rpm, 3.0Gbps | 459318-001 | Mandatory |
| | 500 GB 7,200 rpm, 1.5Gbps | 395501-001 | Mandatory |
| | 500 GB 7,200 rpm, 3.0Gbps | 459319-001 | Mandatory |
| | 750 GB 7,200 rpm, 1.5Gbps | 432401-001 | Mandatory |
| | 750 GB 7,200 rpm, 3.0Gbps | 459320-001 | Mandatory |
| | 1 TB 7,200 rpm, 3.0Gbps | 454273-001 | Mandatory |
| 10 | Backplane two bays SAS/SATA hard drive | 511812-001 | Mandatory ¹ |
| 11 | System fans | 519711-001 | Mandatory ¹ |

System components / 4 3.5" HDD hot-plug model




Table 5 System Components Spare Parts List / 4 3.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|--------------------------------|-----------------------------------|---------------------------------|------------------------|
| 1 | FH/FL riser card | | |
| | PCIex16 | 511808-001 | Mandatory ¹ |
| | PCIX | 511819-001 | Mandatory ¹ |
| 2 | LP PCIe16 riser card | 511809-001 | Mandatory ¹ |
| 3 | Non-hot-plug power supply (500 W) | 506247-001 | Mandatory ¹ |
| 4 | System board | 507255-001 | Mandatory ¹ |
| 5 | Memory modules | | |
| | Registered DIMMs (RDIMMs) | | |
| | DIMM, 2GB 2Rx8 PC3-10600R-9 | 501533-001 | Mandatory |
| | DIMM, 4GB 2Rx4 PC3-10600R-9 | 501534-001 | Mandatory |
| | DIMM, 4GB 4Rx8 PC3-8500R-7 LP | 501535-001 | Mandatory |
| | DIMM, 8GB 2Rx4 PC3-8500R-7 | 519201-001 | Mandatory |
| | Unregistered DIMMs (UDIMMs) | | |
| | DIMM, 1GB 1Rx8 PC3-10600E-9 | 501539-001 | Mandatory |
| | DIMM, 2GB 2Rx8 PC3-10600E-9 | 501540-001 | Mandatory |
| | 6 | Processors, LGA 1366 Xeon™ Xeon | |
| PROC,Xeon EP 2.93 Ghz, 8M, 95W | | 506012-001 | Mandatory ¹ |

Table 5 System Components Spare Parts List / 4 3.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|---|-------------------|------------------------|
| | PROC,Xeon EP 2.67 Ghz, 8M, 95W | 490070-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 80W | 490073-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.0 Ghz, 4M, 80W QC | 490074-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.53 Ghz, 8M, 80W | 490071-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 60W | 508567-001 | Mandatory ¹ |
| 7 | Processor heat sinks | 511803-001 | Mandatory ¹ |
| 8 | Optical disc drive (optional) | | |
| | DRV,ODD, 9.5mm SATA DVD-ROM | 481430-001 | Mandatory ¹ |
| | DRV,ODD, 9.5mm SATA DVD-RW | 481431-001 | Mandatory ¹ |
| 9 | Hard drives | | |
| | 3.5" hot-plug LFF SAS hard drives with carriers | | |
| | 72 GB 15,000 rpm | 376594-001 | Mandatory |
| | 146 GB 15,000 rpm | 376595-001 | Mandatory |
| | 300 GB 15,000 rpm | 432146-001 | Mandatory |
| | 400 GB 10,000 rpm | 456896-001 | Mandatory |
| | 450 GB 15,000 rpm | 454274-001 | Mandatory |
| | 750 GB 7,200 rpm | 461288-001 | Mandatory |
| | 1 TB 7,200 rpm | 461289-001 | Mandatory |
| | 3.5" hot-plug SATA hard drives with carriers | | |
| | 160 GB 7,200 rpm, 1.5Gbps | 353043-001 | Mandatory |
| | 160 GB 7,200 rpm, 3.0Gbps | 483095-001 | Mandatory |
| | 250 GB 7,200 rpm, 1.5Gbps | 353044-001 | Mandatory |
| | 250 GB 7,200 rpm, 3.0Gbps | 459318-001 | Mandatory |
| | 500 GB 7,200 rpm, 1.5Gbps | 395501-001 | Mandatory |
| | 500 GB 7,200 rpm, 3.0Gbps | 459319-001 | Mandatory |
| | 750 GB 7,200 rpm, 1.5Gbps | 432401-001 | Mandatory |
| | 750 GB 7,200 rpm, 3.0Gbps | 459320-001 | Mandatory |
| | 1 TB 7,200 rpm, 3.0Gbps | 454273-001 | Mandatory |
| 10 | Backplane four bays SAS/SATA hard drive | 535348-001 | Mandatory ¹ |
| | Backplane four bays SATA hard drive | 570079-001 | Mandatory ¹ |
| 11 | System fans | 519711-001 | Mandatory ¹ |

System components / 4 3.5" HDD non-hot-plug model




Table 6 System Components Spare Parts List / 4 3.5" HDD Non-hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|-----------------------------------|-------------------|------------------------|
| 1 | FH/FL riser card | | |
| | PClex16 | 511808-001 | Mandatory |
| | PCIX | 511819-001 | Mandatory |
| 2 | LP PCIe16 riser card | 511809-001 | Mandatory |
| 3 | Non-hot-plug power supply (500 W) | 506247-001 | Mandatory |
| 4 | System board | 507255-001 | Mandatory ¹ |
| 5 | Memory modules | | |
| | Registered DIMMs (RDIMMs) | | |
| | DIMM, 2GB 2Rx8 PC3-10600R-9 | 501533-001 | Mandatory |
| | DIMM, 4GB 2Rx4 PC3-10600R-9 | 501534-001 | Mandatory |
| | DIMM, 4GB 4Rx8 PC3-8500R-7 LP | 501535-001 | Mandatory |
| | DIMM, 8GB 2Rx4 PC3-8500R-7 | 519201-001 | Mandatory |
| | Unregistered DIMMs (UDIMMs) | | |
| | DIMM, 1GB 1Rx8 PC3-10600E-9 | 501539-001 | Mandatory |
| | DIMM, 2GB 2Rx8 PC3-10600E-9 | 501540-001 | Mandatory |

Table 6 System Components Spare Parts List / 4 3.5" HDD Non-hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|-------------|--|--------------------------|-----------------------------|
| 6 | Processors, LGA 1366 Xeon™ Xeon | | |
| | PROC,Xeon EP 2.93 Ghz, 8M, 95W | 506012-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.67 Ghz, 8M, 95W | 490070-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 80W | 490073-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.0 Ghz, 4M, 80W QC | 490074-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.53 Ghz, 8M, 80W | 490071-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 60W | 508567-001 | Mandatory ¹ |
| 7 | Processor heat sinks | 511803-001 | Mandatory ¹ |
| 8 | Optical disc drive (optional) | | |
| | DRV,ODD, 9.5mm SATA DVD-ROM | 481430-001 | Mandatory |
| | DRV,ODD, 9.5mm SATA DVD-RW | 481431-001 | Mandatory |
| 9 | Hard drives | | |
| | 3.5"non- hot-plug SATA hard drives with carriers | | |
| | 160 GB 7,200 rpm | 459314-001 | Mandatory |
| | 250 GB 7,200 rpm | 373313-001 | Mandatory |
| | 500 GB 7,200 rpm | 404654-001 | Mandatory |
| | 750 GB 7,200 rpm | 463047-001 | Mandatory |
| 10 | System fans | 519711-001 | Mandatory |

System components / 8 2.5" HDD hot-plug model




Table 7 System Components Spare Parts List / 8 2.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|-----------------------------------|-------------------|------------------------|
| 1 | FH/FL riser card | | |
| | PCIex16 | 511808-001 | Mandatory ¹ |
| | PCIX | 511819-001 | Mandatory ¹ |
| 2 | LP PCIe16 riser card | 511809-001 | Mandatory ¹ |
| 3 | Non-hot-plug power supply (500 W) | 506247-001 | Mandatory ¹ |
| 4 | System board | 507255-001 | Mandatory ¹ |
| 5 | Memory modules | | |
| | Registered DIMMs (RDIMMs) | | |
| | DIMM, 2GB 2Rx8 PC3-10600R-9 | 501533-001 | Mandatory |
| | DIMM, 4GB 2Rx4 PC3-10600R-9 | 501534-001 | Mandatory |
| | DIMM, 4GB 4Rx8 PC3-8500R-7 LP | 501535-001 | Mandatory |
| | DIMM, 8GB 2Rx4 PC3-8500R-7 | 519201-001 | Mandatory |
| | Unregistered DIMMs (UDIMMs) | | |
| | DIMM, 1GB 1Rx8 PC3-10600E-9 | 501539-001 | Mandatory |
| | DIMM, 2GB 2Rx8 PC3-10600E-9 | 501540-001 | Mandatory |
| 6 | Processors, LGA 1366 Xeon™ Xeon | | |
| | PROC,Xeon EP 2.93 Ghz, 8M, 95W | 506012-001 | Mandatory ¹ |

Table 7 System Components Spare Parts List / 8 2.5" HDD Hot-plug Model

| Item | Description | Spare Part Number | Customer Self Repair |
|------|--|-------------------|------------------------|
| | PROC,Xeon EP 2.67 Ghz, 8M, 95W | 490070-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 80W | 490073-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.0 Ghz, 4M, 80W QC | 490074-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.53 Ghz, 8M, 80W | 490071-001 | Mandatory ¹ |
| | PROC,Xeon EP 2.26 Ghz, 8M, 60W | 508567-001 | Mandatory ¹ |
| 7 | Processor heat sinks | 511803-001 | Mandatory ¹ |
| 8 | Optical disc drive (optional) | | |
| | DRV,ODD, 9.5mm SATA DVD-ROM | 481430-001 | Mandatory ¹ |
| | DRV,ODD, 9.5mm SATA DVD-RW | 481431-001 | Mandatory ¹ |
| 9 | Hard drives | | |
| | 2.5" hot-plug SAS hard drives with carriers | | |
| | 36 GB 15,000 rpm DP | 418397-001 | Mandatory |
| | 72 GB 10,000 rpm SP | 376597-001 | Mandatory |
| | 72 GB 10,000 rpm DP | 389346-001 | Mandatory |
| | 72 GB 15,000 rpm SP | 432321-001 | Mandatory |
| | 72 GB 15,000 rpm DP | 418398-001 | Mandatory |
| | 146 GB 10,000 rpm SP | 432320-001 | Mandatory |
| | 146 GB 10,000 rpm DP | 418399-001 | Mandatory |
| | 146 GB 15,000 rpm DP | 504334-001 | Mandatory |
| | 300 GB 10,000 rpm DP | 493083-001 | Mandatory |
| | 2.5" hot-plug SATA hard drives with carriers | | |
| | 120 GB 5,400 rpm | 459322-001 | Mandatory |
| | 250 GB 5,400 rpm | 460426-001 | Mandatory |
| | 500 GB 5,400 rpm | 508035-001 | Mandatory |
| 10 | Backplane eight bays SAS/SATA hard drive | 532481-001 | Mandatory ¹ |
| 11 | System fans | 519711-001 | Mandatory ¹ |

¹Mandatory—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

²Optional—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

³No—Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

¹Mandatory: Obligatoire—Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

²Optional: Facultatif—Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

³No: Non—Certains pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

¹Mandatory: Obbligatorie—Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.

²Optional: Opzionali—Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto.

³No: Non CSR—Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

¹Mandatory: Zwingend—Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand- und Arbeitskosten für diesen Service berechnet.

²Optional: Optional—Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

³No: Kein—Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

¹Mandatory: Obligatorio—componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

²Optional: Opcional—componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

³No: No—Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

¹Mandatory: Verplicht—Onderdelen waarvoor Customer Self Repair verplicht is. Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening.

²Optional: Optioneel—Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garantieservice voor het product.

³No: Nee—Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

¹Mandatory: Obrigatória—Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

²Optional: Opcional—Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

³No: Nenhuma—Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

HP contact information

For the name of the nearest HP authorized reseller:

- In the United States, call 1-800-345-1518.
- In Canada, call 1-800-263-5868.
- In other locations, refer to the HP website at <http://www.hp.com/>.

For HP technical support:

- In North America:
 - Call 1-800-HP-INVENT (1-800-474-6836). This service is available 24 hours a day, 7 days a week. For continuous quality improvement, calls may be recorded or monitored.
 - If you have purchased a Care Pack (service upgrade), call 1-800-633-3600. For more information about Care Packs, refer to the HP website at <http://www.hp.com/>.
- Outside North America, call the nearest HP Technical Support Phone Center. For telephone numbers for worldwide Technical Support Centers, refer to the HP website at <http://www.hp.com/>.

Before you contact HP

Be sure to have the following information available before you call HP:

- Technical support registration number (if applicable)
- Product serial number
- Product model name and number
- Applicable error messages
- Add-on boards or hardware model number and serial number
- Third-party hardware or software model number
- Operating system type and revision level

Removal and replacement procedures

This chapter provides subassembly/module-level removal and replacement procedures for the HP ProLiant DL160se G6 server.

Review the specifications of a new component before installing it to make sure it is compatible with the server. When you integrate new components into the system, record its model and serial number, and any other pertinent information for future reference. After completing any removal or replacement procedure, run the diagnostics program to verify that all components operate properly.

NOTE: The figures used in this chapter to illustrate procedural steps are labeled numerically (i.e., 1, 2...). When these figures are used in substep items, the alphabetically labeled instructions correspond to the numbered labels on the related figure (i.e., label 1 corresponds to step a, label 2 corresponds to step b, etc.). The procedures described in this section assume that the server is out of the rack and is positioned on a flat, stable surface.

Hardware configuration tools

You will need the following tools:

- T-10/T-15 wrench

The following references and software tools will assist with the hardware configuration:

- HP ProLiant DL160se G6 Server Easy Set-up CD
- IPMI Event Log
- Diagnostics Software

Hardware configuration information

Electrostatic discharge information

An electrostatic discharge (ESD) can damage static-sensitive devices or micro circuitry. Proper packaging and grounding techniques are necessary precautions to prevent damage. To prevent electrostatic damage, observe the following precautions:

- Transport products in static-safe containers such as conductive tubes, bags, or boxes.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Cover workstations with approved static-dissipating material. Use a wrist strap connected to the work surface, and properly grounded (earthed) tools and equipment.
- Keep work area free of nonconductive materials, such as ordinary plastic assembly aids and foam packing.
- Make sure that you are always properly grounded (earthed) when touching a static-sensitive component or assembly.
- Avoid touching pins, leads, or circuitry.
- Always place drives with the Printed Circuit Board (PCB) assembly-side down.
- Use conductive field service tools.

Pre-installation procedure

Perform the steps below before you open the server or before you remove or replace any component.



WARNING: Failure to properly turn off the server before you open the server or before you start installing and removing components may cause serious damage as well as bodily harm.

1. Turn off the server and all the peripherals connected to it.
2. Unplug all cables from the power outlet(s) to avoid exposure to high energy levels that may cause burns when parts are short-circuited by metal objects such as tools or jewelry.
If necessary, label each one to expedite reassembly.
3. Disconnect telecommunication cables to avoid exposure to shock hazard from ringing voltages.
4. If server is installed in a rack, remove server and place it on a flat surface.
5. Remove the top cover according to the instructions described in the “System cover” section in this chapter.
6. Follow the ESD precautions listed previously in this chapter when handling a server component.



IMPORTANT: To streamline the configuration process, read through the entire installation and removal procedures first and make sure you understand them before you begin.




Post-installation instructions

Observe the following items after installing or removing a server component:

1. Be sure all components are installed according to the described step-by-step instructions.
2. Reinstall the rear cage, air baffle, peripherals, and system cables that you have removed.
3. Reinstall the top cover.
4. Reinstall server into rack.
5. Connect all external cables and the AC power cord(s) to the system.
6. Press the power button on the front panel to turn on the server.



Server warnings and cautions

Before installing a server, be sure that you understand the following warnings and cautions.

-
-  **WARNING:** To reduce the risk of electric shock or damage to the equipment:
- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
 - Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.
 - Unplug the power cord from the power supply to disconnect power to the equipment.
 - Do not route the power cord where it can be walked on or pinched by items placed against it. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server.
-
-  **WARNING:** To reduce the risk of personal injury from hot surfaces, allow the drives and the internal system components to cool before touching them.
-
-  **CAUTION:** Do not operate the server for long periods with the system cover open or removed. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage.
-

HP Trusted Platform Module

The TPM is not a customer-removable part.

-
-  **CAUTION:** Any attempt to remove an installed TPM from the system board breaks or disfigures the TPM security rivet. Upon locating a broken or disfigured rivet on an installed TPM, administrators should consider the system compromised and take appropriate measures to ensure the integrity of the system data.
-
-  **IMPORTANT:** If you suspect a TPM board failure, leave the TPM installed and remove the system. Contact an HP authorized service provider for a replacement system board and TPM board.
-

Symbols on equipment

The following symbols may be placed on equipment to indicate the presence of potentially hazardous conditions.



This symbol indicates the presence of hazardous energy circuits or electric shock hazards. Refer all servicing to qualified personnel.

WARNING: To reduce the risk of injury from electric shock hazards, do not open this enclosure. Refer all maintenance, upgrades, and servicing to qualified personnel.



This symbol indicates the presence of electric shock hazards. The area contains no user or field serviceable parts. Do not open for any reason.

WARNING: To reduce the risk of injury from electric shock hazards, do not open this enclosure.



This symbol on an RJ-45 receptacle indicates a network interface connection.

WARNING: To reduce the risk of electric shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into this receptacle.



This symbol indicates the presence of a hot surface or hot component. If this surface is contacted, the potential for injury exists.

WARNING: To reduce the risk of injury from a hot component, allow the surface to cool before touching.



Weight in kg.
Weight in lb.

This symbol indicates that the component exceeds the recommended weight for one individual to handle safely.

WARNING: To reduce the risk of personal injury or damage to the equipment, observe local occupational health and safety requirements and guidelines for manual material handling.



These symbols, on power supplies or systems, indicate that the equipment is supplied by multiple sources of power.

WARNING: To reduce the risk of injury from electric shock, remove all power cords to completely disconnect power from the system.

Powering down the server

The server does not completely power down when the power button on the front panel is pressed. The button toggles between On and Standby. The standby position removes power from most electronics and the drives, but some internal circuitry remains active. To completely remove all power from the system, disconnect all power cords from the server.

To power down the server:

1. Shut down the server as directed by the operating system documentation.
2. Press the power button to toggle to Standby.

This places the server in standby mode changing the power LED indicator to amber. In this mode, the main power supply output is disabled. Standby does not completely disable or remove power from the system.

3. Disconnect the AC power cord(s) from the power outlet(s) and then from the server.
4. Be sure that the power LED indicator is turned off and that the fan noise has stopped.
5. Disconnect all peripheral devices from the server.

System cover


You need to remove the top cover before you can remove or replace a server component. The top cover needs to be removed to service the SAS/SATA backplane.

Top cover

To remove the top cover:

1. Loosen the screw on the top cover with a T-10 wrench.
2. Press the latch on the top cover.
3. Slide the cover toward the rear of the server and then lift the top cover to remove it from the chassis. Lift the top cover away from the chassis.


Figure 1 Removing the Top Cover



To reinstall the top cover:

1. Align the top cover to the chassis and then slide it towards the front panel to position it into place.
2. Once the cover is attached to the chassis, tighten the screw on the top cover with a T-10 wrench.

Figure 2 Reinstalling the Top Cover



Drives

The server supports the following configurations:

- 2 drive bays for 3.5-inch hard disk drives and 1 drive bay for an optical disc drive.
- 4 drive bays for 3.5-inch hard disk drives and 1 drive bay for an optical disc drive.
- 8 drive bays for 2.5-inch hard disk drives and 1 drive bay for an optical disc drive.

Cable management

Always follow good cable management practices when working inside the computer.


- Keep cables away from major heat sources like the heat sink.
- Do not jam cables on top of expansion cards or memory modules. Printed circuit cards are not designed to withstand excessive pressure.
- Keep cables clear of sliding or moveable parts to prevent cutting or crimping.
- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases may damage the wires.
- Some flat ribbon cables come pre-folded. Never change the folds on these cables.
- Do not sharply bend any cable. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in.) radius.
- Never crease a SATA data cable.
- Do not rely on components like the drive cage, power supply, or system cover to push cables down into the chassis.

The next steps illustrate the removal of power cable from connector J51, 60 and 64 on system board.

1. Squeeze on the top of the retaining latch attached to the cable end of the connector.
2. Grasp the cable end of the connector and pull it straight up.

⚠ CAUTION: Always pull the connector—NEVER pull on the cable. Pulling on the cable could damage the cable and result in a failed power supply.

Figure 3 Unplugging Power Cable



Cable connections

The following tables provide information about switching power supply cable connector labels.

Table 8 Cable connections from the 460W/750 W Hot-plug Power Supply (Optional)

| Cable | To | Cable Designator |
|------------------------|--|------------------|
| Switching power supply | System board 24-pin power connector | P1 |
| Switching power supply | System board 8-pin power connector | P2 |
| Switching power supply | System board 4-pin power connector | P3 |
| Switching power supply | Optical disc drive | CD |
| Switching power supply | System board power backplane connector | RPS |
| Switching power supply | Graph card power connector | P4 |
| Switching power supply | 4/8 HDD hot-plug Backplane power connector | P5 |
| Switching power supply | 4 Non hot-plug HDD | P6,P7,P8,P9 |
| Switching power supply | 2 HDD hot-plug Backplane power connector | P10/P11 |

NOTE: P6,P7,P8,P9,P10 and P11 are extended connectors from P5, P4 are the extended 6-pin connector from 10-pin P4 connector of power supply.

Table 9 Cable connections from the 500 W Non-hot-plug Power Supply

| Cable | To | Cable Designator |
|-------|----|------------------|
|-------|----|------------------|

Table 9 Cable connections from the 500 W Non-hot-plug Power Supply

| Cable | To | Cable Designator |
|------------------------|--|------------------|
| Switching power supply | System board 24-pin power connector | P1 |
| Switching power supply | System board 8-pin power connector | P2 |
| Switching power supply | System board 4-pin power connector | P3 |
| Switching power supply | Graph card power connector | P4 |
| Switching power supply | Optical disc drive | P5 |
| Switching power supply | 4 HDD hot-plug Backplane power connector | P7 |
| Switching power supply | 2 HDD hot-plug Backplane power connector | P10 |
| Switching power supply | 4 Non hot-plug HDD | P11,P12,P13,P14 |

NOTE: P8,P10,P11,P12,P13,P14 are extended connectors from P7

The following tables provide the system board designators that various cables plug into. For more detailed information about system board components, see “Figure 96 System Board Components”.

Table 10 Cable Connections from the System Board

| Cable | To | System Board Designator |
|--|---------------------|-------------------------|
| 20-pin front panel connector | Front panel | J42 |
| USB 0/1 connector | Front panel USB 2.0 | J53 |
| USB 4 connector | Internal USB 2.0 | J69 |
| 24-pin power connector | Power supply | J51 |
| 8-pin power connector | Power supply | J64 |
| 4-pin power connector | Power supply | J60 |
| 3-pin backplane I ² C connector | Backplane | J65 |
| 12-pin power supply EFF connector | Power supply | J79 |
| 16-pin power backplane control connector | Power supply | J76 |
| 6-pin system fan 1 connector | System fan 1 | J63 |
| 6-pin system fan 2 connector | System fan 2 | J71 |
| 6-pin system fan 3 connector | System fan 3 | J62 |
| 6-pin system fan 4 connector (optional) | System fan 4 | J70 |
| 6-pin system fan 5 connector | System fan 5 | J68 |
| 6-pin system fan 6 connector | System fan 6 | J67 |
| LCD connector (optional) | Optional LCD module | J56 |

Table 11 Drive Cable Connections / 2 3.5" Hot-plug HDD Model

| Cable | To | System Board Designator |
|------------------|--------------------|-------------------------|
| SATA 1 connector | Backplane | J41 |
| SATA 2 connector | Backplane | J49 |
| SATA 3 connector | Optical disc drive | J52 |

Table 12 Drive Cable Connections / 4 3.5" Hot-plug HDD Model

| Cable | To | System Board Designator |
|------------------|--------------------|-------------------------|
| SATA 1 connector | Backplane | J41 |
| SATA 2 connector | Backplane | J49 |
| SATA 3 connector | Backplane | J52 |
| SATA 4 connector | Backplane | J55 |
| SATA 5 connector | Optical disc drive | J57 |

Table 13 Drive Cable Connections / 4 3.5" Non-hot-plug HDD

| Cable | To | System Board Designator |
|------------------|--------------------|-------------------------|
| SATA 1 connector | HDD 1 | J41 |
| SATA 2 connector | HDD 2 | J49 |
| SATA 3 connector | HDD 3 | J52 |
| SATA 4 connector | HDD 4 | J55 |
| SATA 5 connector | Optical disc drive | J57 |

Table 14 Drive Cable Connections / 8 2.5" Non-hot-plug HDD

| Cable | To | System Board Designator |
|-----------------------------|----------------------|--|
| PCI storage controller card | 8 2.5" HDD Backplane | 3 rd party Mini-SAS connector 1 |
| PCI storage controller card | 8 2.5" HDD Backplane | 3 rd party Mini-SAS connector 2 |
| SATA 5 connector | Optical disc drive | J57 |


Drive bay configuration

The server supports the following drive bays:

- 2 drive bays for 3.5 in. hard disk drives and 1 drive bay for 9.5mm (0.37 in.) optical disc drive.

- 4 drive bays for 3.5 in. hard disk drives, or 4 drive bays for 3.5 in. hard disk drives and 1 drive bay for 9.5mm (0.37 in.) optical disc drive.
- 8 drive bays for 2.5-inch hard disk drives and 1 drive bay for 9.5mm (0.37 in.) optical disc drive.


Figure 4 System Drive Bays / 2 3.5" Hot-plug HDD Model



| Item | Description |
|------|--|
| 1 | 9.5mm (0.37 in.) optical disk drive (optional) |
| 2 | 3.5 in. hard disk drive bays (2) |

The HDD bays support both SATA and SAS drives.


Figure 5 System Drive Bays / 4 3.5" HDD Hot-plug Model



| Item | Description |
|------|--|
| 1 | 9.5mm (0.37 in.) optical disk drive (optional) |
| 2 | 3.5 in. hard disk drive bays (4) |

The HDD bays support both SATA and SAS drives.


Figure 6 System Drive Bays / 4 3.5" HDD Non-hot-plug Model



| Item | Description |
|------|--|
| 1 | 9.5mm (0.37 in.) optical disk drive (optional) |
| 2 | 3.5 in. hard disk drive bays (4) |

The HDD bays can support SATA drives.

Figure 7 System Drive Bays / 8 2.5" Hot-plug HDD Model



| Item | Description |
|------|-------------------------------------|
| 1 | 9.5mm (0.37 in.) optical disk drive |
| 2 | 2.5 in. hard disk drive bays (8) |

The HDD bays support both SATA and SAS drives.


Optical disc drive Bay

The optical media device bays of the servers with 2 HDDs and 4 HDDs and 8 HDDs support a 9.5 mm (0.37 in.) DVD ROM. The following procedure is an example using the server with 4 HDDs model.

To remove the optical disk drive carrier:


1. Remove the top cover and then unplug the SATA and power cables.
2. Loosen the screws.

Figure 8 Removing the Cables and Screws



3. Push the optical disk drive toward the front of the unit.
4. Pull the optical disk drive out of the chassis.

Figure 9 Removing the Optical disk drive



IMPORTANT: If you removed an optical disk drive without plans of installing a new one, you must reinstall the blank to maintain proper system airflow.


To remove the bezel blank:

1. Turn off the server and all the peripherals connected to it.
2. Unplug all external cables and AC power cords. If necessary, label each one to expedite reassembly.
3. Remove the unit from the rack and place on a flat surface.
4. Remove the top cover.
5. Pull the bezel blank out of the carrier.



CAUTION: Do not discard the bezel blank. If the optical disk drive is removed in the future, you must reinstall the bezel blank to maintain proper system function.


Figure 10 Removing the Bezel Blank



To install the optical disk drive:

1. Slide the optical disk drive assembly into the chassis.
2. Remove the top cover, fasten the screws and connect the IDE data and power cables to their corresponding connectors on the optical disk drive.

Figure 11 Installing the Optical disk drive




Hard drives

The drive bays on the front panel can accommodate up to two or eight hard drives. You can install either SAS hard drives or SATA hard drives in the server.

For servers with 2 3.5-inch HDDs, the hard drives installed in the server are labeled from Device 1 to Device 2, from left to right, when viewed from the front of the server.


Figure 12 Hard Drive Configuration / 2 3.5" HDD Hot-plug Model



| Item | Description |
|------|--------------------------|
| 1-2 | SAS/SATA hard drives 1-2 |


For servers with 4 3.5-inch HDDs, the hard drives installed in the server are labeled from Device 1 to Device 4, from left to right, when viewed from the front of the server.

Figure 13 Hard Drive Configuration / 4 3.5" HDD Hot-plug Model



| Item | Description |
|------|--------------------------|
| 1-4 | SAS/SATA hard drives 1-4 |

Figure 14 Hard Drive Configuration / 4 3.5" HDD Non-hot-plug Model




| Item | Description |
|------|-------------|
|------|-------------|

| | |
|-----|----------------------|
| 1-4 | SATA hard drives 1-4 |
|-----|----------------------|

For servers with 8 2.5-inch HDDs, the hard drives installed in the server are labeled from Device 1 to Device 8, from top to bottom, left to right, when viewed from the front of the server.

Figure 15 Hard Drive Configuration / 8 2.5" Hot-plug HDD Model



| Item | Description |
|------|-------------|
|------|-------------|


| | |
|-----|--------------------------|
| 1-8 | SAS/SATA hard drives 1-8 |
|-----|--------------------------|

The hot-plug HDD for the servers with 2 3.5" HDDs and 4 3.5" HDDs and 8 2.5" HDDs share the same replacement procedures. Here we take the server with 4 3.5" HDDs as an example for your reference.

To remove the hot-plug hard drive:

1. Press the hard disk carrier button to release the ejector lever.
2. Use the HDD carrier latch to pull the drive out of the cage.
Make sure to support the drive when pulling it out of the cage.
3. Pull the hard drive assembly out of the drive bay.


Figure 16 Removing the Hot-plug Hard Drive Assembly



To install the hot-plug hard drive:

1. Press the release tabs, and then pull the hard drive blank out of the chassis.

Figure 17 Removing the Hot-plug Hard Drive Blank




IMPORTANT: Do not discard the hard drive blank. If the drive is removed in the future, you must reinstall the hard drive blank to maintain proper system airflow.

2. Install a hard drive.
 - a. Push the hard drive assembly into the drive bay until it stops.

- b. Press the HDD carrier latch inward until it clicks.


Figure 18 Installing the Hot-plug Hard Drive Assembly



To remove the non-hot-plug hard drive:


1. Disconnect the SATA and power cable.
2. Loosen the screw with the T-10/T-15 wrench provided.

Figure 19 Loosening the Screw



3. Push the hard drive toward the front of the unit
4. Pull the hard drive assembly out of the drive bay.


Figure 20 Removing the Non-hot-plug Hard Drive Assembly



To remove a non-hot-plug hard drive disk from the carrier:

1. Loosen the four screws on the carrier (two on each side).
2. Lift the hard drive from the carrier.


Figure 21 Removing the Non-hot-plug Hard Drive Disk



To install a non-hot-plug hard drive disk into the carrier:

1. Put the non-hot-plug hard drive disk into the carrier.
2. Fasten the HDD to the carrier using the screws (two on each side).


Figure 22 Installing the Non-hot-plug Hard Drive Disk into the Carrier



To install a non-hot-plug hard drive into the server:


1. Remove the hard drive blank from the front of the system if installed.
2. Push the hard drive assembly into the drive bay until it stops.

Figure 23 Installing the Non-hot-plug Hard Drive Assembly



3. Fasten the screw with the T-10/T-15 wrench provided to secure the hard drive to the chassis.
4. Connect the cabling from the HDD backplane to the drive using the cables provided.


Figure 24 Fastening the Screw



SAS/SATA HDD backplane


The following figures show the front and back side of the backplane.

Figure 25 Backplane Connectors of Server with 2 HDDs (component side)




| Item | Description |
|------|------------------------|
| 1 | Screw holes |
| 2 | LED indicators |
| 3 | Headers for hard drive |

Figure 26 SAS Backplane Connectors of Server with 4 HDDs (component side)




| Item | Description |
|------|------------------------|
| 1 | Screw holes |
| 2 | LED indicators |
| 3 | Headers for hard drive |

Figure 27 SATA Backplane Connectors of Server with 4 HDDs (component side)



| Item | Description |
|------|------------------------|
| 1 | Screw holes |
| 2 | LED indicators |
| 3 | Headers for hard drive |


Figure 28 Backplane Connectors of Server with 8 HDD (component side)



| Item | Description |
|------|-------------|
|------|-------------|

| | |
|---|------------------------|
| 1 | LED indicators |
| 2 | Screw holes |
| 3 | Headers for hard drive |

Figure 29 Backplane Connectors of Server with 2 HDDs (solder side)




| Item | Description |
|------|-------------|
|------|-------------|

| | |
|---|----------------------------|
| 1 | Power connector |
| 2 | PROG connector |
| 3 | I ² C connector |


| Item | Description |
|------|--------------------|
| 4 | Mini SAS connector |

Figure 30 SAS Backplane Connectors of Server with 4 HDDs (solder side)



| Item | Description |
|------|----------------------------|
| 1 | Power connector |
| 2 | Mini SAS connector |
| 3 | PROG connector |
| 4 | I ² C connector |


Figure 31 SATA Backplane Connectors of Server with 4 HDDs (solder side)



| Item | Description |
|------|-------------|
|------|-------------|

| Item | Description |
|------|----------------------------|
| 1 | Power connector |
| 2 | I ² C connector |
| 3 | SGPIO connector |
| 4 | SATA connectors |

Figure 32 Backplane Connectors of Server with 8 HDD (solder side)



| Item | Description |
|------|----------------------------|
| 1 | PIC 2 PROG connector |
| 2 | Power connector |
| 3 | I ² C connector |
| 4 | PIC 1 PROG connector |
| 5 | Mini SAS connectors |

⚠ WARNING: Ensure that the system is powered off and all power sources have been disconnected from the server. Voltages are present at various locations within the server whenever an AC power source is connected. This voltage is present even when the main power switch is in the off position.


To remove the backplane:

The backplanes for the servers with 2 HDDs and 4 HDDs and 8 HDDs share the same replacement procedures. Here we take the SAS backplane for the server with 4 HDDs as an example for your reference.

1. Remove all drives out of the drive bays.
Refer to the “Optical disc drive Bay” and “Hard drives” sections in this chapter for detailed procedures.
2. Remove the top cover.
3. Remove all cables connected to the backplane.


4. Remove the hard drive cage.
 - a. Loosen all screws that secure the hard drive cage to the chassis.
 - b. Slide the hard drive cage out and then lift it up. Remove the hard drive cage from the chassis.

Figure 33 Removing the Hard Drive Cage



5. Remove the backplane.
 - c. Remove all cables including optical disk drive cables.
 - d. Remove the three screws that secure the backplane to the hard drive cage.
 - e. Pull the backplane up and out to release it from the hard drive cage.


Figure 34 Removing the Backplane



To reinstall the backplane:

1. Orient the backplane so that the notches on the backplane align with the hook on the drive cage and then press the backplane down until it clicks into place.
2. Secure the backplane with three screws.

Figure 35 Reinstalling the Backplane



3. Install all cables.

System board configuration


Processor

HP ProLiant DL160se G6 Server supports quad core processors. If a single processor is installed, then use socket 1. When two processors are used, the server supports boot functions through the processor installed in socket 1. However, if processor 1 fails, the system cannot boot up, and if processor 2 fails, the system will be automatically booted from processor 1 and provide a processor failure message.

The processor socket supports 2P Intel Xeon processor with integrated memory controller.

CAUTION: It is recommended to use processors of the same speeds or cache sizes to prevent possible server malfunction.

Figure 36 Processor Locations



| Item | Description |
|------|-------------|
|------|-------------|

| | |
|---|-------------|
| 1 | Processor 1 |
|---|-------------|

| | |
|---|-------------|
| 2 | Processor 2 |
|---|-------------|


WARNING: To reduce the risk of personal injury from hot surfaces, allow the heat sink and the processor to cool before touching them.

NOTE: Before installing the processor, remove the air baffle.

To remove the air baffle:

1. Gently rock the air baffle up.
2. Take the air baffle out from the system board.

Figure 37 Removing the Air Baffle




To remove the heat sink:

1. Loosen the two spring-loaded screws.
2. Lift the heat sink away from the system board.

CAUTION: Place the heat sink down in an upright position with the thermal patch facing upward. Do not let the thermal patch touch the work surface.

Figure 38 Removing the Heat Sink Assembly




IMPORTANT: If the heat sink has been removed for any reason on a previously installed processor, it is critical that you apply more grease compound to the integrated heat spreader on the processor to ensure proper thermal bonding between the processor and the heat sink.

△ CAUTION: Do not over-tighten the spring-loaded screws to prevent them from breaking off. A maximum torque of 6 inch-lb is set for each screw. Rotate the heat sink a few degrees to the left and right to break the bonding of the thermal grease compound before removing the heat sink from the processor.

To remove the processor:

1. Unlock the load lever and lift it up.
2. Open the retention plate.
3. Grasp the processor by its edges and lift it out of its socket.

Figure 39 Removing the Processor



△ CAUTION: The pins of the socket are very fragile. Do not bend or damage them.

△ CAUTION: Place the processor on a static-dissipating work surface or in an anti-static bag.


△ CAUTION: To allow heat sink to draw as much heat as possible from the processor base, there must be good contact between the heat sink base and the top of the processor. To ensure good contact, you must apply thermal grease compound.

To apply the thermal grease compound:

1. Use a clean cloth dipped in rubbing alcohol to clean the contact surface on the heat sink and the new processor. Wipe the contact surfaces several times to make sure that no particles or dust contaminants are evident.
2. Apply the thermal grease compound to the integrated heat spreader on the processor in one of the following patterns to insure even distribution.

△ CAUTION: HP recommends using Shin-Etsu X-23-7783D thermal grease compound for your ProLiant server. Apply the grease to the top of the processor in either a 5 "Dot" or "S" shaped pattern. Ensure even distribution.

Figure 40 The bottom of the heat sink




△ CAUTION: Never touch the bottom of the processor; any contaminant could prevent the mounting pads from making contact with the socket.

△ CAUTION: Applying too much grease creates a gap between the contact surfaces, significantly reducing the ability of the heat sink to draw out heat. Installing the heat sink with excessive grease can also cause the grease to spread over the processor pins or the system board base, which can cause electrical shorts that damage the system.

To install the new processor:

1. Insert the processor into the socket, using the key on the processor.
2. Engage the retention plate and the load lever

Figure 41 Inserting the Processor




CAUTION: With the load lever and the retention plate disengaged, hold the processor by its edges and align it over the empty processor socket. Make sure that you properly align the processor with the orientation notch on the socket.

CAUTION: To prevent overheating or a possible system crash, use only a heat sink model specified for the HP ProLiant DL160se G6 server.

To install the heat sink:

1. Properly align the heat sink spring-loaded screws to the system board mounting holes.
2. Tighten the spring-loaded screws clockwise to secure the heat sink connection to the system board.

Figure 42 Installing the Heat Sink Assembly




CAUTION: When installing two heat sinks, please keep the label on the heat sink towards the T-mark guide orientation on the system board.

CAUTION: For proper cooling, do not operate the server without the top cover, air baffle, expansion slot covers, or blanks installed. For additional information, see the user guide. If hot-plug components are supported, minimize the amount of time the top cover is removed.

To install the air baffle:

1. Connect all necessary cables.
2. Gently place the air baffle on the system board.

Figure 43 Installing the Air Baffle



Memory

The system board has twelve DIMM slots that support up to 96 GB maximum system memory (8 GB in each of the twelve DIMM slots).

You must adhere to the following guidelines when adding or replacing memory modules:

- For 2P system, both physical processors must be of the same type and speed.
- Use 800/1066/1333 MHz DDR3 RDIMM/UDIMM.
- Installation guide for 1P configuration:
 - Follow the sequence of 2A, 4B, 6C, 1D, 3E, and 5F for the corresponding processor when installing the memory.
- Installation guide for 2P configuration:
 - Follow the sequence of 2A, 4B, 6C, 1D, 3E, and 5F for the corresponding processor when installing the memory.
 - Install at least one memory DIMM for each processor.
 - The memory quantity installed for each processor can be different.

Figure 44 DIMM Population





Figure 45 DIMM Slots




NOTE: Before installing the memory, remove the air baffle first. For a detailed procedure, see the "Processor" section in this chapter.

To remove the memory module:

1. Completely open the holding clips securing the memory module.
2. Gently pull the memory module upward to remove it from the slot.

Figure 46 Removing the Memory Module




⚠ CAUTION: Place the memory module on a static-dissipating work surface or inside of an anti-static bag.

To install the memory module:

1. Align the notch on the bottom edge of the memory module with the keyed surface of the DIMM slot and then fully press the memory module into the slot until the holding clips snap back in place.

Figure 47 Installing the Memory Module



⚠ CAUTION: The DIMM slots are structured to ensure proper installation. If you insert a DIMM but it does not fit easily into the slot, you may have inserted it incorrectly. Reverse the orientation of the DIMM and insert it again.


DIMM identification



IMPORTANT: This server does not support mixing RDIMMs and UDIMMs. Attempting to mix these two types causes the server to halt during BIOS initialization.

The memory subsystem may be populated with either RDIMMs or UDIMMs, but mixing the two types is not supported. To determine DIMM characteristics, use the label attached to the DIMM and the following illustration and table.

Figure 48 DIMM identification




| Item | Description | Definition |
|------|--------------|---|
| 1 | Size | — |
| 2 | Rank | 1R = Single-rank 2R = Dual-rank 4R = Quad-rank |
| 3 | Data width | x4 = 4-bit x8 = 8-bit |
| 4 | Memory speed | 10600 = 1333-MHz 8500 = 1067-MHz |
| 5 | DIMM type | R = RDIMM (registered) E = UDIMM (unbuffered with ECC) |

PCI expansion card

System board PCI expansion slot

There are three PCI expansion slots on the system board.

Figure 49 System Board PCI Expansion Slots




| Item | Component Designator | Component | Function |
|------|----------------------|--------------------------|------------------------------------|
| 1 | J31 | PCIe X4 (FH/FL) slot 1b | Support a PCIe or PCI-X riser card |
| 2 | J17 | PCIe X16 (FH/FL) slot 1a | Support a PCIe or PCI-X riser card |
| 3 | J18 | PCIe X16 (LP) slot 2 | Support a PCIe or PCI-X riser card |

PCI riser card expansion slot

The three PCIe riser cards attached to the PCI cage converts the functionality of the system board expansion slot to the slot positioned at a 90° angle from the system board.


NOTE: Users have the option to install a single slot PCI-X Riser Card using Slot 1a&1b on the system board or to replace the single Slot PCI Express riser card in Slot 1a and slot 2 with a PCI-X model using the PCI-X riser card option kit. This will allow support for PCI-X devices.

Figure 50 PCIe x16 Full-Height/Full-Length Riser Card Connector Location (the riser card for slot 1a)




- Single-slot PCIe riser card (x16 link with x16 slot)

Figure 51 PCIe x16 Low Profile Riser Card Connector Location (the riser card for slot 2)



- Single-slot PCIe riser card (x16 link with x16 slot)

Figure 52 PCIX Riser Card Connector Location (the riser card for slot 1a and 1b)



- Single-slot PCIe riser card (x16 and x4 link with X slot)


PCI cage

To remove the PCI cage:

NOTE: Disconnect all cables connecting an existing expansion board to the system board.

1. Loosen the four screws that secure the PCI cage to the system board tray.
2. Lift the PCI cage away from the system board assembly.

Figure 53 Removing the PCI Cage



Installing PCIe/PCI-X riser cards

The system supports up to two riser cards at a time. Use only HP supported expansion boards that meet the following specifications:

- Compliance
 - PCIe x16
 - PCI-X (available only when the optional PCI-X riser card is installed)
- Form Factor
 - Low Profile
 - Full-Height/Full-Length

To remove the PCIe riser card:

1. Loosen the two screws securing the riser card to the PCI cage.
2. Remove the riser card from the PCI cage.

Figure 54 Removing the PCIe x16 Full-Height/Full-Length Riser Card




Figure 55 Removing the PCIe x16 Low Profile Riser Card





Figure 56 Removing the PCIX Full-Height/Full-Length Riser Card



To install the PCIe riser card:

1. Align the screw holes on the riser card to the screw holes on the PCI cage.
2. Install and tighten the screws that secure the riser card to the PCI cage.

Figure 57 Installing the PCIe x16 Full-Height/Full-Length Riser Card




Figure 58 Installing the PCIe x16 Low Profile Riser Card





Figure 59 Installing the PCIe PCIX Full-Height/Full-Length Riser Card



To install the PCI expansion board:

1. Remove the screw near the slot cover on the PCI cage.

Figure 60 Removing the Screw on the PCI Cage on the Full-height / Full-length Side





Figure 61 Removing the Screw on the PCI Cage on the Low-profile Side



2. Remove the slot cover from the PCI cage.
3. Slide the expansion board into the slot, aligning the board with its matching connector. Firmly press the board to seat it properly on the slot.
4. Fasten the screw to secure it.

Figure 62 Installing the PCI Expansion Board (1)





Figure 63 Installing the PCI Expansion Board (2)



CAUTION: Do not discard the slot cover. If the expansion board is removed in the future, the slot cover must be reinstalled to maintain proper cooling.

To reinstall the PCI cage:

1. Install the PCI expansion board into the PCI cage.
 - f. Align the PCI expansion board with the open expansion slot.
 - g. Press the PCI expansion board into the expansion slot on the riser card.
2. Align the PCI cage to the system board expansion slot, and then press it down to ensure full connection to the system board.
3. Tighten the four screws to secure the PCI cage to the chassis.

Figure 64 Reinstalling the PCI Cage with PCI Expansion Board (1)





Figure 65 Reinstalling the PCI Cage with PCI Expansion Board (2)




4. Connect the necessary cable(s) to the system board.

Dedicated management port (Optional)

The server can support a dedicated management port. The dedicated management port is optional for the shipment.

The following figure shows the dedicated management port location.


Figure 66 Dedicated management port Location



To remove the dedicated management port:


1. Remove the PCI cage assembly out of the chassis. Refer to the "PCI expansion card " section in this chapter for detailed procedures.
2. Loosen the screw.
3. Pull the dedicated management port upwards, and then remove the dedicated management port from the dedicated management port connector.

Figure 67 Removing the Dedicated management port



4. Remove the spacer from the system board.


Figure 68 Removing the Spacer



To reinstall the dedicated management port:


1. Remove the mgmt port cover.

Figure 69 Removing the Mgmt Port Cover




2. Insert the spacer into the system board.

Figure 70 Inserting the Spacer



3. Insert the dedicated management port into the dedicated management port connector.
4. Tighten the screw clockwise to secure the dedicated management port to the system board.

Figure 71 Reinstalling the Dedicated management port




System battery

The server uses nonvolatile memory that requires a system battery to retain system information when power is removed.

This 3 V lithium coin cell battery is located on the system board.

Figure 72 System Battery Location



⚠ WARNING: Note the following reminders when replacing the system battery:

- Replace the system battery with the same type as the system battery recommended by HP. Use of another system battery may present a risk of fire or explosion.
- A risk of fire and chemical burn exists if the system battery is not handled properly. Do not disassemble, crush, puncture, or short external contacts, or expose the system battery to temperatures higher than 60°C (140°F).
- Do not dispose of used system battery in water or fire. Dispose of used system battery according to manufacturer's instructions.

⚠ CAUTION: Loss of BIOS settings occurs when the system battery is removed. You must reconfigure BIOS settings whenever you replace the system battery.

NOTE: If the server no longer automatically displays the correct date and time, you may need to replace the system battery. Under normal usage, system battery life is five to ten years.


To replace the system battery:

1. Power down the server.
2. Disconnect the power cord(s).
3. Unlock the server if necessary and remove the top cover as described in the section "System cover".

NOTE: If the expansion board is installed to the PCI cage, remove the PCI cage before releasing the battery. Refer to the "PCI cage" section in this chapter for detailed procedures.

4. Release the battery from its holder by squeezing the metal clamp that extends above one edge of the battery. When the battery pops up, lift it out.
5. To insert the new battery, slide one edge of the replacement battery under the holder's lip with the positive side up. Push the other edge down until the clamp snaps over the other edge of the battery.


Figure 73 Replacing the System Battery



BBWC (Optional)

This server can support a BBWC. The BBWC is optional for the shipment.


Figure 74 BBWC Location



To remove the BBWC assembly:

1. Push the tab that secures the BBWC assembly to the system board tray.
2. Slide the BBWC assembly, and then lift it out of the system board assembly.


Figure 75 Removing the BBWC Assembly



To reinstall the BBWC assembly:

1. Align the locking tabs on the BBWC assembly to their holes on the tray.
2. Press the BBWC assembly into the tray, and then push it along the direction of the arrow to lock the locking tabs.

Figure 76 Reinstalling the BBWC Assembly




System board removal and replacement procedure

To remove the system board:

1. Remove the top cover.
2. Remove the air baffle and all cables from the system board.
3. Loosen the nine screws that secure the system board to the chassis.
4. Slide the system board back, up and out of the chassis. Remove the system board from the chassis.


Figure 77 Removing the System Board



To reinstall the system board:

1. Align the system board I/O connectors to their openings and slide the system board into place. The nine screw holes on the chassis should align with the system board.
2. Fasten the nine screws on the system board to secure the system board to the chassis.


Figure 78 Reinstalling the System Board



Power supply unit (PSU)

Located on the rear panel of the server power supply is a standard autoranging 500 W non-hot-plug PSU, or optional 750 W or optional 460 W hot-plug PSU with PFC (power factor correction) function.


Figure 79 Hot-plug Power Supply Unit (Optional)



To remove the hot-plug power supply:

1. Press the port wine colored tab.
2. Slide the hot-plug power supply out of the power supply bay.

Figure 80 Removing the Hot-plug Power Supply



To reinstall the hot-plug power supply:

1. Align the hot-plug power supply cage connector with the open power supply bay and slide the power supply into the chassis.
2. Snap the latch cover over port colored handle. Latch cover only installs one way.

Figure 81 Reinstalling the Hot-plug Power Supply





Figure 82 Non-hot-plug Power Supply Unit




⚠ WARNING: Take note of the following reminders to reduce the risk of personal injury from electric shock hazards and/or damage to the equipment.

- Installation of power supply units should be referred to individuals who are qualified to service server systems and are trained to deal with equipment capability of generating hazardous energy levels.
- **DO not** open the power supply unit. There are no serviceable parts inside it.

To remove the non-hot-plug power supply:


1. Loosen the two screws that secure the power supply, which are located beneath the chassis.

Figure 83 Loosening the Two Screws beneath the Chassis



2. Loosen the screws that secure the power supply to the chassis.
3. Pull and lift the power supply out of the chassis.


Figure 84 Removing the Non-hot-plug Power Supply



To reinstall the non-hot-plug power supply:


1. Locate and push the power supply to the proper place in the chassis.
2. Fasten the power supply to the chassis using the screws as shown in the figure below.

Figure 85 Reinstalling the Non-hot-plug Power Supply



3. Fasten the two screws which are located beneath the chassis to secure the power supply.

Figure 86 Fastening the Two Screws beneath the Chassis




System fan

The server has six system fans located on the center wall of the chassis, one is optional.

The figure below identifies the system fans by their device number and shows their corresponding cable connections.

Figure 87 System Fan Connections




| Device number | Connector |
|----------------------------|-------------------------|
| System fan 1 | J63 on the system board |
| System fan 2 | J71 on the system board |
| System fan 3 | J62 on the system board |
| System fan 4 (optional) | J70 on the system board |
| System fan 5 | J68 on the system board |
| System fan 6 | J67 on the system board |

A new system fan can be installed to allow the server to operate properly in case a default system fan becomes defective.

To remove the system fan:

1. Power down the server.
2. Disconnect the power cord(s).
3. Unlock the server if necessary and remove the top cover as described in the section "System cover".
4. Disconnect the system fan cable from its corresponding board connector.
5. Release the fan cable from the cable clip securing it to the chassis partition wall.
6. Lift the system fan away from the chassis.


Figure 88 Removing the System Fan



To reinstall the system fan:

1. Put the system fan cable through the system fan cage.
2. Hold the system fan and press the system fan into the system fan bracket.
3. Connect the system fan cable to its corresponding board connector.

Figure 89 Reinstalling the System Fan




Connectors, switches, and LEDs

This chapter contains illustrations and tables identifying and describing the connectors, jumpers, switch, buttons, and LED indicators located on the front panel, rear panel, system board and hard drives of the HP ProLiant DL160se G6 server.

Connectors and components

Front panel components


Figure 90 Front Panel Components / 2 3.5" HDD Hot-plug Model



| Item | Description |
|------|-------------------------------|
| 1 | Thumbscrews for rack mounting |
| 2 | Drive online/error LED |
| 3 | Drive activity LED |
| 4 | Optical disc drive (optional) |
| 5 | Serial number pull tab |
| 6 | Front panel USB 2.0 port 0/1 |
| 7 | Front UID LED/switch |
| 8 | System health LED |
| 9 | NIC 1 activity LED |
| 10 | Power LED/switch |
| 11 | Hard drive activity LED |


| Item | Description |
|------|----------------------------|
| 12 | NIC 2 activity LED |
| 13 | Hard disk drive (HDD) bays |

Figure 91 Front Panel Components / 4 3.5" HDD Hot-plug Model




| Item | Description |
|------|-------------------------------|
| 1 | Thumbscrews for rack mounting |
| 2 | Drive online/error LED |
| 3 | Drive activity LED |
| 4 | Optical disc drive (optional) |
| 5 | Serial number pull tab |
| 6 | Front panel USB 2.0 port 0/1 |
| 7 | Front UID LED/switch |
| 8 | System health LED |
| 9 | NIC 1 activity LED |
| 10 | Power LED/switch |
| 11 | Hard drive activity LED |
| 12 | NIC 2 activity LED |
| 13 | Hard disk drive (HDD) bays |

Figure 92 Front Panel Components / 4 3.5" HDD Non-hot-plug Model



| Item | Description |
|------|-------------------------------|
| 1 | Thumbscrews for rack mounting |
| 2 | Optical disc drive (optional) |
| 3 | Serial number pull tab |
| 4 | Front panel USB 2.0 port 0/1 |
| 5 | Front UID LED/switch |
| 6 | System health LED |
| 7 | NIC 1 activity LED |
| 8 | Power LED/switch |
| 9 | Hard drive activity LED |
| 10 | NIC 2 activity LED |
| 11 | Hard disk drive (HDD) bays |


Figure 93 Front Panel Components / 8 2.5" HDD Model



| Item | Description |
|------|-------------------------------|
| 1 | Thumbscrews for rack mounting |
| 2 | Drive online/error LED |
| 3 | Drive activity LED |
| 4 | Serial number pull tab |
| 5 | Optical disc drive |
| 6 | Front panel USB 2.0 port 0/1 |
| 7 | Front UID LED/switch |
| 8 | System health LED |
| 9 | NIC 1 activity LED |
| 10 | Power LED/switch |
| 11 | Hard drive activity LED |
| 12 | NIC 2 activity LED |
| 13 | Hard disk drive (HDD) bays |


Rear panel components

Figure 94 Rear Panel Components / Hot-plug Power Supply Model (Optional)



| Item | Description |
|------|---|
| 1 | Power supply cable socket |
| 2 | Serial port |
| 3 | VGA port |
| 4 | GbE LAN port for NIC 2 |
| 5 | Dedicated management port (optional) |
| 6 | Low-profile PCI expansion card slot cover |
| 7 | Full-height/full-length PCI expansion card slot cover |
| 8 | T-10/T-15 wrench |
| 9 | Screws for PCI cage |
| 10 | Rear UID LED/switch |
| 11 | GbE LAN port for NIC 1 |
| 12 | Rear panel USB 2.0 port 2/3 |


Figure 95 Rear Panel Components / Non-hot-plug Power Supply Model



| Item | Description |
|------|---|
| 1 | Power supply cable socket |
| 2 | Serial port |
| 3 | VGA port |
| 4 | GbE LAN port for NIC 2 |
| 5 | Dedicated management port (optional) |
| 6 | Low-profile PCI expansion card slot cover |
| 7 | Full-height/full-length PCI expansion card slot cover |
| 8 | T-10/T-15 wrench |
| 9 | Screws for PCI cage |
| 10 | Rear UID LED/switch |
| 11 | GbE LAN port for NIC 1 |
| 12 | Rear panel USB 2.0 port 2/3 |

System board components

Figure 96 System Board Components



| Item | Designator | Description |
|------|------------|--|
| 1 | J17 | PCIe slot |
| 2 | J11 | Dedicated management port connector |
| 3 | J18 | PCIe slot |
| 4 | J21 | DIMM slot 6C for processor 2 |
| 5 | J26 | DIMM slot 1D for processor 2 |
| 6 | CPU2 | Processor 2 |
| 7 | J48 | DIMM slot 6C for processor 1 |
| 8 | J60 | 4-pin power connector |
| 9 | J43 | DIMM slot 1D for processor 1 |
| 10 | J51 | System power connector |
| 11 | CPU1 | Processor 1 |
| 12 | J63 | Fan 1 connector |
| 13 | J71 | Fan 2 connector |
| 14 | J64 | 8-pin power connector |
| 15 | J62, J70 | Fan connectors 3/4 (fan 4 connector is optional) |
| 16 | J69 | Internal USB 2.0 port 4 |
| 17 | J65 | Backplane I ² C connector |
| 18 | J68, J67 | Fan connectors 5/6 |
| 19 | J66 | Hard drive backplane SGPIO connector |
| 20 | J79 | Power supply EFF connector |

| Item | Designator | Description |
|------|------------|-----------------------------------|
| 21 | B1 | 3 V CMOS battery (CR2032) |
| 22 | J76 | Backplane power control connector |
| 23 | J56 | LCD connector (optional) |
| 24 | J53 | Front panel USB 2.0 port 0/1 |
| 25 | J42 | Front panel header |
| 26 | J29 | TPM Connector |
| 27 | J27 | System maintenance jumper |
| 28 | SATA | SATA connectors |
| 29 | J31 | PCIe slot |

Jumpers

The system board contains a system maintenance jumper (J27). **Table 15** describes the jumper settings.

Table 15 System Maintenance Jumper Settings (J27)

| Jumper | Status (default=off) |
|--------|----------------------|
| A | Clear CMOS |
| B | Clear password |
| C | Recovery BIOS |
| D | Recovery BMC |
| E | RTC reset |

LED indicators

This section contains illustration and descriptions of internal and external status LED indicators located on the:

- Front panel
- Optical disk drive
- Hard drive
- Rear panel
- System board

These LED indicators aid in problem diagnosis by indicating the status of system components and operations of the server.

Front panel LED indicators

The front panel LED indicators allow constant monitoring of basic system functions while the server is operating.

Figure 97 Front Panel LED Indicators




Table 16 Front Panel LED Indicator Status

| Item | LED indicator | Status | Description |
|------|----------------------|---------------|--------------------------------------|
| 1 | Front UID LED/switch | Steady blue | Identification |
| | | Flashing blue | The system is being remotely managed |
| | | Off | No identification |
| 2 | System health LED | Steady green | Healthy |
| | | Red | Critical error |
| | | Amber | Non-critical error |
| 3 | NIC 1 activity LED | Steady green | Linked to the network |

Table 16 Front Panel LED Indicator Status

| Item | LED indicator | Status | Description |
|------|-------------------------|----------------|--|
| | | Flashing green | Linked and activity on the network. |
| | | Off | No connection |
| 4 | NIC 2 activity LED | Steady green | Linked to the network |
| | | Flashing green | Linked and activity on the network. |
| | | Off | No connection |
| 5 | Hard drive activity LED | Flashing green | Hard drive activity |
| | | Off | No hard drive activity |
| 6 | Power LED/switch | Steady green | The system has AC power and is turned on. |
| | | Steady amber | The system has AC power but in standby mode. |
| | | Off | No AC power to the system. |

Optical disk drive activity LED indicator

The optical disk drive has an activity indicator that indicates when the drive is reading media.

Figure 98 Optical disk drive activity LED indicator




Table 17 Optical disk drive Activity LED Indicator Status

| Item | LED indicator | Status | Description |
|------|---|----------------|------------------------|
| 1 | Optical disk drive activity LED indicator | Flashing green | Ongoing drive activity |
| | | Off | No drive activity |

Hard Drive LED indicators

The status of hard drives installed in the server is indicated by the online LED indicator located on the HDD.

Figure 99 Hard Drive LED Indicator




Table 18 Hard Drive LED Indicator Status

| Item | LED indicator | Status | Description |
|------|----------------------------------|----------------|--|
| 1 | Drive online/error LED indicator | Steady blue | The drive is located. |
| | | Steady orange | The drive is in a failed state. |
| | | Off | The drive is not in a failed state. |
| 2 | Drive activity LED indicator | Flashing green | The drive is in an activity state. |
| | | Off | The drive is not in an activity state. |

Rear panel LED indicators

The LAN port on the rear panel has two LED indicators that allow monitoring of network activity.

Figure 100 LAN LED Indicators Location




Table 19 LAN LED Indicator Status

| Item | Component | Status | Description |
|------|---|----------------|--|
| 1 | NIC activity LED indicator | Flashing green | Linked and activity on the network. |
| | | Off | No connection or linking at 10 Mbps speed. |
| 2 | NIC link LED indicator | Flashing green | LAN is active. |
| | | Steady green | LAN is link. |
| | | Off | No connection. |
| 3 | Dedicated management LAN port activity LED indicator (optional) | Flashing amber | LAN is active. |
| 4 | Dedicated management LAN port link LED indicator (optional) | Steady green | Linking at 100 Mbps speed. |
| | | Off | No connection or linking at 10 Mbps speed. |

System board LED indicator

The system board contains one LED indicator for use during troubleshooting operations.

Figure 101 System Board LED Indicator




Table 20 BMC activity LED Indicator Status

| Item | Component | Status | Description |
|------|----------------------------|----------------|--|
| 1 | BMC activity LED indicator | Steady green | BMC is power on and in initialization process. |
| | | Flashing green | BMC activity. |
| | | Off | AC is Off. |

Diagnostic tools and setup utilities

This chapter provides an overview of the Power-On Self-Test (POST), the POST error messages, and BIOS, SAS and SATA setup utilities.

BIOS software

The server uses BIOS to boot up the system. BIOS software is a ROM-based firmware that allows reliability, manageability, and connectivity for server platforms. This software contains a set of programs permanently stored in an EEPROM chipset located on the system board. These programs assist in managing, initializing, and testing the hardware devices installed on the computer.

BIOS software allows you to:

- Perform configuration from the BIOS Setup Utility
Using the Setup Utility, you can install, configure, and optimize the hardware devices on the system board. In addition, you can set various features such as serial console redirection, PXE boot, and much more.
- Initialize hardware at boot up using POST routines
During power-on or warm reset, the BIOS perform POST routines to test system components, allocate resource for various hardware devices, and prepare the system to boot to various operating systems.

BIOS Setup Utility

The HP server BIOS Setup Utility is used to configure five primary menu selections:

- Main
- Advanced
- Boot
- Security
- Exit

Accessing the BIOS Setup Utility

1. Turn on the monitor and server.
If the server is already turned on, save your data and exit from all open applications, and then restart the server.
2. When the HP logo is displayed during POST, press **F10** into BIOS Setup Utility. If you fail to press **F10** before POST is completed, you will need to restart the server.
3. The first page displayed is the Main menu showing the Setup Utility menu bar. Use the left (←) and right (→) arrow keys to change the options for each setting. Use the up (↑) and down (↓) arrow keys to move among the different settings in each menu.

Navigating through the Setup Utility

Use the keys listed in the legend bar on the right of the Setup screen to navigate through the various menu and submenu screens of the Setup Utility. **Table 21** lists these legend keys and their respective functions.

Table 21 Setup Utility Navigation Keys

| Key | Function |
|--------------------------|---|
| ← and → | Select different screens. |
| ↑ and ↓ | Select items in each menu. |
| Enter, Tab, or Shift-Tab | Select a field value or display a submenu screen. Display more options for items marked with ► |
| Esc | Exit the CMOS Setup menu. |
| <+>, <-> | Configure the system time or change field. |
| F1 | To bring up the General Help window. The General Help window describes other Setup navigation keys that are not displayed on the legend bar. |
| F10 | To save changes and exit the CMOS Setup Utility. |

Setup Utility menu bar

The BIOS Setup Utility provides a menu bar with the menu selections. The menu bar choices are described in the topics below.

Main menu

Figure 102 Main Menu of the BIOS Setup Utility

| ROM-based Setup Utility | | |
|---|---------------------|--|
| <Main> Advanced Boot Security Exit | | |
| System Overview | | User [ENTER], [TAB] or [SHIFT-TAB] to select a field. |
| Product Name: | Proliant DL160se G6 | |
| ProLiant BIOS: | O20 | |
| Build Date: | 03/05/2009 | Use [+] or [-] to configure system time. |
| ROM ID | 12DIM102 | |
| Processor | | |
| Intel(R) Xeon(R) CPU | X5570 @ 2.93GHz | |
| Speed: | 2933MHz | |
| Count: | 1 | |
| System Memory | | ←→ Select Screen |
| Size: | 2048MB | ↑↓ Select Item |
| | | + - Change Field |
| System Time | [09:41:43] | Tab Select Field |
| System Date | [Thu 03/05/2009] | F1 General Help |
| System Serial Number | | F10 Save and Exit |
| NIC#1 MAC Address | 00-23-7D-A1-44-98 | ESC Exit |
| NIC#2 MAC Address | 00-23-7D-A1-44-99 | |
| Asset Tag | [] | |
| POST F1 Prompt | [Delayed] | |
| V02. 61(C) Copyright 1985-2006, American Megatrends, Inc. | | |

Use this menu to set the system time and date, and configure the following items:

- View product name.
- View BIOS build date and ROM ID.
- View processor information and system memory size.
- Set system time and date.
- View system serial number.
- 1 View NIC 1&2 MAC addresses.
- 2 Configure asset tags and POST F1 Prompt settings.

Figure 104 IPMI Submenu of the BIOS Setup Utility

| ROM-based Setup Utility | | |
|---|--|--|
| <Advanced> | | |
| IPMI 2.0 Configuration | InPut for Set LAN Configuration command. | |
| Status of BMC | Working | |
| BMC Firmware Revision | 04.00 | |
| BMC/IPMI FW Date: | Jan/09/2009 | |
| BMC SDR Version: | 2.17.0.43 | |
| >Set LAN Configuration | NOTE: - Each question in this group may take considerable amount of time. ←→ Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit | |
| >SEL Configuration | | |
| >Hardware Health Information | | |
| >Watchdog Configuration | | |
| >Serial Port Configuration | | |
| V02. 61(C) Copyright 1985-2006, American Megatrends, Inc. | | |

- **Status of BMC**—Display the status of BMC.
- **BMC Firmware Revision**—Display the current revision of the BMC firmware.
- **BMC/IPMI FW Date**—Display the date of the BMC/IPMI firmware.
- **BMC SDR Version**—Display the current version of the BMC SDR.
- **Set LAN Configuration**—Set LAN settings.
- **SEL Configuration**—Display and clear the BMC system event log.
- **Hardware Health Information**—Set temperature and fan rotation rate.
- **Watchdog Configuration**—Configure watch dog timer status.
- **Serial Port Configuration**—Configure serial port connection settings.

Boot menu

Figure 105 Boot Menu of the BIOS Setup Utility

| ROM-based Setup Utility | |
|--|--|
| Main Advanced <Boot> Security Exit | |
| Boot Settings | Configure Settings during System Boot. |
| > Boot Settings Configuration >Standard Boot Order >Hard Disk Drives USB Device Boot Priority [High] Restore on AC Power Loss [Last State] | |
| | □□ Select Screen □□ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit |
| V02. 61(C) Copyright 1985-2006, American Megatrends, Inc. | |

- **Boot Settings Configuration**— Configure settings during system boot.
- **Standard Boot Order**—View and configure standard boot order settings.
- **Hard Disk Drives**—Display HDD information if detect HDD installed.
- **USB Device Boot Priority**— Configure priority settings for USB devices. Users can configure the BIOS to avoid attempting to boot non-bootable USB devices that are left plugged into the server during POST. The options are **High** (default) and **Low**.
- **Restore on AC Power Loss**—View and configure settings to restore AC power loss.

Exit menu

Figure 107 Exit Menu of the BIOS Setup Utility

| ROM-based Setup Utility | |
|--|---|
| Main Advanced Boot Security <Exit> | |
| Exit Options | Exit system setup after saving the changes. |
| Save Changes and Exit | F10 key can be used for this operation.. |
| Discard Changes and Exit | |
| Discard Changes | |
| Restore Default Settings | |
| □□ Select Screen □□ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit | |
| V02. 61(C) Copyright 1985-2006, American Megatrends, Inc. | |

Use this menu to save changes or discard changes. When you save and exit, the server reboots.

- **Save Changes and Exit**—Save the changes you have made and exit the BIOS Setup Utility.
- **Discard Changes and Exit**—Exit the BIOS Setup Utility without saving the changes you have made.
- **Discard Changes**—Discard (cancel) any changes you have made. **F10** can be used for this operation. You will remain in the Setup Utility.
- **Restore Default Settings**—Restore the default settings for all items in the BIOS Setup.

BIOS update

HP recommends that you update the server BIOS with the latest system BIOS version to take advantage of the most recent compatibility fixes. The latest BIOS version for your server can be downloaded from <http://www.hp.com>.

Clear CMOS

You may need to clear the Setup configuration values (CMOS) if the configuration has been corrupted, or if incorrect settings made in the Setup Utility have caused error messages to be unreadable.

To clear CMOS:

1. Perform the Pre-installation procedure.
2. If necessary, remove any accessory boards or cables that prevent access to the system configuration switch.
3. Locate the system maintenance jumper (J27) on the system board.
4. Press the button. AC power must not be connected.
5. Perform the Post-installation instructions.
6. During POST, press **F10** to access the Setup Utility.
7. Load setup defaults by pressing **F9**.
8. Set time, date, and other system values.
9. Press **F10** to close the Setup Utility.

NOTE: Clearing CMOS restore all system configurations and password default settings.

Power-On Self-Test (POST)

Before you can use a server, all devices must be tested and initialized, and the operating system must be bootstrapped to the memory. This is referred to as Power-On Self-Test or POST. POST is a series of diagnostic tests that checks firmware and hardware components on the system to ensure that the server is properly functioning. This diagnostic function automatically runs each time the server is powered on.

These diagnostics, which reside in the BIOS ROM, isolate server-related logic failures and indicate the board or component that you need to replace, as indicated by the error messages. Most server hardware failures will be accurately isolated during POST. The number of tests displayed depends on the configuration of the server.

During POST you can:

- Press **ESC** to skip the HP logo and go to POST boot progress display system summary screen.
- Press **F10** to access the Setup Utility.
- Press **F12** to request a network boot (PXE).
- Press **F1** to continue POST after POST errors are detected.

POST error indicators

When POST detects a system failure, it displays a POST error message.

POST error descriptions

When a non-fatal error occurs during POST, the screen will display an error message with the format “xxx-Error Identifier String” where “xxx” is a unique number code that matches ODM system specific error documentation and may be a hexadecimal or decimal value.

All Error messages describe the problems as shown below:

Table 22 POST Error Messages

| Error code | Description |
|------------|---|
| 10 | Floppy Controller Failure |
| 00B | CMOS Memory Size Wrong |
| 00C | RAM R/W test failed |
| 003 | CMOS Battery Low |
| 005 | CMOS Checksum Bad |
| 040 | Refresh timer test failed |
| 041 | Display memory test failed |
| 048 | Password check failed |
| 120 | \$A0CCMOS Cleared by Jumper. Restore the Jumper and Continue... |
| 122 | \$A0CPassword Cleared By Jumper. Restore the Jumper and Continue... |
| 150 | Processor failed BIST |
| 160 | Processor missing microcode: |
| 192 | L3 cache size mismatch |
| 193 | CPUID, Processor stepping are different |
| 194 | CPUID, Processor family are different |
| 195 | Front side bus mismatch. System halted. |
| 196 | CPUID, Processor Model are different |
| 197 | Processor speeds mismatched |
| 198 | Processor QPI speed mismatch detected. |
| 601 | Error: BMC Not Responding |
| 605 | BMC Has Detected Fatal Hardware Error |
| 611 | Internal User Area Of BMC FRU Corrupted |
| 612 | Controller Update 'boot block' Firmware Corrupted |
| 613 | Controller Operational Firmware Corrupted |

Table 22 POST Error Messages

| Error code | Description |
|------------|--|
| 620 | Non-Redundant Fan Failure or Missing |
| 621 | Redundant Fan Configuration, One Fan Failure or Missing |
| 622 | Redundant Fan Configuration, Multiple Fans Failure or Missing |
| 623 | Temperature Violation Detected Waiting 5 minutes for system to cool Press ESC Key to resume booting without waiting for the system to cool Warning: Pressing ESC is NOT recommended as the system may shutdown unexpectedly |
| 624 | Power Supply Failure or Power Supply Unplugged |
| 626 | Update SDRR/Configuration Image failed |
| 627 | Invalid or Unknown SKU/Chassis ID Please check Front panel, System ID Jumper or Riser card Press F1 to Continue |
| 628 | Redundant Power Supply Mismatch |
| 701 | Insufficient Runtime space for MPS data.!!. System may operate in PIC or Non-MPS mode. |
| 702 | No enough APIC ID in range 0-0Fh can be assigned to IO APICs. (Re-assigning CPUs' local APIC ID may solve this issue) MPS Table is not built! System may operate in PIC or Non-MPS mode. |

POST related troubleshooting

Perform the following procedures when POST fails to run, displays error messages.

If the POST failure is during a routine boot up, check the following:

- All external cables and power cables should be firmly plugged in.
- The power outlet to the server should be connected and works correctly.
- The server and monitor are both turned on. The bicolour status LED indicator on the front panel must be lit up green.
- The monitor's contrast and brightness settings are correct.
- All internal cables are properly connected and all boards firmly seated.
- The processor is fully seated in its socket on the system board.
- The heat sink assembly is properly installed on top of the processor.
- All memory modules are properly installed.
- If you have installed a PCI accessory board, verify that the board is firmly seated and any jumpers on the board are properly set. Refer to the documentation provided with the accessory board.
- All internal cabling and connections are in their proper order.
- If you have changed the jumpers on the system board, verify that each is properly set.

SETSYS utility

SETSYS.EXE (DOS application) is the correct tool for setting the Serial Number/Asset Tag text on this server after a system board replacement has occurred.

Once the Serial Number/Asset Tag text has been entered via SETSYS, populating the SMBIOS data, the system BIOS will automatically write this info into the BMC IPMI FRU data on the next boot up.

Physical and operating specifications

This chapter provides physical and operating specifications for the HP ProLiant DL160se G6 server. Specifications include:

System unit

Table 23 Hardware Specifications

| Item | Components |
|-----------------------------|---|
| Processor socket | Intel FCLGA1366 socket |
| Processor | 2P Intel Xeon processor with integrated memory controller |
| Chipset | Tylersberg-36D/ICH-10R |
| Hardware monitoring device | ServerEngines Pilot 2 management controller |
| Gigabit ethernet controller | HP NC362i GbE controller for NIC LO100i sideband support |
| Onboard storage controller | Integrated ICH10R SATA (6-port) |
| ODD & Floppy interface | Optional optical disk driver (SATA) Optional Floppy (USB only, USB key) |
| Embedded video controller | ServerEngines Pilot 2 management controller |
| I/O subsystem | One PCIe x16 links with x16 slot + PCIe x4 links with x4 slot One PCIe x16 links with x16 slot |
| Memory | Twelve DDR3 800/1066/1333 MHz RDIMM/UDIMM slots, up to 96 GB |
| Default media storage | Two bays hot-plug HDD cage for 3.5" SAS or SATA drives Four bays hot-plug HDD cage for 3.5" SAS or SATA drives Four bays non-hot-plug HDD cage for 3.5" SATA drives Eight bays hot-plug HDD cage for 2.5" SAS or SATA drives |
| Optical media storage | One slim optical disk drive bay for DVD-ROM drive on the front |
| I/O ports | USB 2.0 ports (two rear USB ports, one internal USB port, two front USB ports), video port, serial port and GbE port and IPMI LAN port. |

Table 23 Hardware Specifications

| Item | Components |
|-----------------------|--|
| Status LED indicators | System Health LED |
| Front panel | NIC 1/2 activity LED Power Switch/LED Hard drive activity LED indicator UID Switch/LED |
| Rear panel | UID LED LAN link status BMC Activity LED |
| System board | |
| Power supply unit | 500 W non-hot-plug, power supply 460 W hot-plug, power supply 750 W hot-plug, power supply |
| Thermal solution | Six system fans, one is optional |

Table 24 Physical Dimensions

| Item | Description |
|---------------------------------------|--|
| System board platform | EATX (Extended Advanced Technology Extended) |
| System board dimension | 304.8 mm x 330.2 mm (12 in x 13 in) |
| Server dimensions (H x W x D) Rack | 43 mm x 448 mm x 713 mm (1.69 in. x 17.64 in. x 28.07 in.) |
| Server weight | Basic configuration (excludes monitor): 14~20kg |

Table 25 Environmental Specifications

| Item | Description |
|------------------------------------|---|
| Temperature: | |
| Operating | +10°C to +35°C (+50°F to +95°F) |
| Non-operating | -30°C to 60°C (-22°F to 140°F) |
| Storage | -30°C to 60°C (-22°F to 140°F) |
| Wet-bulb temperature | 38.7°C (101.7°F) |
| Relative humidity: | |
| Operating | 10% to 90% (non-condensing) |
| Non-operating | 5% to 95% |
| Storage | 5% to 95% |
| Altitude: | |
| Operating | 0 to 3049 m (0 to 10,000 ft) |
| Non-operating | 0 to 9146 m (0 to 30,000 ft) |
| Thermal output (maximum operating) | 1000 W/hr |
| Acoustic emissions | LWad: 6.7 Bels |
| Normal configuration | (operating at room temperature) LWad: 6.7 Bels (Idle at room temperature) |

Table 26 Power Supply Specifications / 460 W Hot-plug

| Item | Description |
|----------------------------|--|
| Dimensions (H x W x D) | 38.48 mm x 86.36 mm x 190.5 mm (1.52 in x 3.4 in x 7.5 in) |
| Weight (approximate) | 1.36 kg |
| Input requirements: | |
| Rated input voltage | 90 VAC to 264 VAC |
| Normal line voltage | 100 VAC to 120 VAC/200 VAC to 240 VAC |
| Line frequency | 47–63 Hz |
| Rated input current | 6.0 ARMS max @ 100 V 5.0 ARMS max @ 120 V 3.00 ARMS max @ 200 V to 240 V |
| BTU rating | N/A |
| Power supply output power: | |
| Rated steady state power | 460 W |
| Maximum peak power | N/A |
| Temperature range: | |
| Operating | +5°C to +50°C |
| Shipping | - 40°C to +85°C |
| Relative humidity: | |
| Operating | 5% to 95% relative humidity, non-condensing |
| Non-operating | 5% to 95% relative humidity, non-condensing |

Table 27 Power Supply Specifications / 500 W Non-hot-plug

| Item | Description |
|----------------------------|---|
| Dimensions (H x W x D) | 40 mm x 86 mm x 280 mm (1.57 in x 3.39 in x 11.02 in) |
| Weight (approximate) | 1.36 kg |
| Input requirements: | |
| Rated input voltage | 90 VAC to 264 VAC |
| Normal line voltage | 100 VAC to 120 VAC/200 VAC to 240 VAC |
| Line frequency | 47–63 Hz |
| Rated input current | 10.0 ARMS max @ 100 V to 120 V 5.0 ARMS max @ 200 V to 240 V |
| BTU rating | N/A |
| Power supply output power: | |
| Rated steady state power | 500 W |
| Maximum peak power | N/A |

Table 27 Power Supply Specifications / 500 W Non-hot-plug

| Item | Description |
|--------------------|---|
| Temperature range: | |
| Operating | +5°C to +50°C |
| Shipping | - 40°C to +85°C |
| Relative humidity: | |
| Operating | 5% to 95% relative humidity, non-condensing |
| Non-operating | 5% to 95% relative humidity, non-condensing |

Table 28 Power Supply Specifications / 750 W Hot-plug

| Item | Description |
|----------------------------|--|
| Dimensions (H x W x D) | 38.48 mm x 86.36 mm x 190.5 mm (1.52 in x 3.4 in x 7.5 in) |
| Weight (approximate) | 1.36 kg |
| Input requirements: | |
| Rated input voltage | 90 VAC to 264 VAC |
| Normal line voltage | 100 VAC to 120 VAC/200 VAC to 240 VAC |
| Line frequency | 47–63 Hz |
| Rated input current | 9.10 ARMS max @ 100V 5.10 ARMS max @ 200V |
| BTU rating | N/A |
| Power supply output power: | |
| Rated steady state power | 750 W |
| Maximum peak power | N/A |
| Temperature range: | |
| Operating | +5°C to +50°C |
| Shipping | - 40°C to +85°C |
| Relative humidity: | |
| Operating | 5% to 95% relative humidity, non-condensing |
| Non-operating | 5% to 95% relative humidity, non-condensing |

Index

A

- AC power
 - power-down procedures, 36
- air baffle
 - installing, 67
 - removing, 63

B

- backplane, 55
 - reinstalling, 60
 - removing, 59
- battery
 - replacement warnings, 85

BBWC

- reinstalling, 87
- removing, 86

bezel blank

- removing, 46

BIOS Setup Utility

- accessing, 109
- additional navigation keys, 110
- menu bar, 109

BIOS software

- overview, 109

C

- cable connections, 39
- cable management, 38
- CSR (customer self repair), 5
- CSR program
 - part categories, 6
 - website, 5
- customer self repair (CSR), 5

D

- dedicated management port
 - reinstalling, 83
 - removing, 82
- diagnostic tools and setup utilities
 - BIOS Setup Utility, 109
 - BIOS software, 109
 - BIOS update, 117

POST, 117

Diagnostic tools and Setup Utilities

- clear CMOS, 117
- drive bay configuration, 41
- drives

- backplane, 55
- cable connections, 39
- cable management, 38
- drive bay configuration, 41
- hard drives, 47
- optical disc drive, 45

E

electric shock

- symbol, 35
- warning, 35

environmental specifications, 123

exploded view

- Mechanical Components Spare Parts List / 2 or 4 3.5, 16
- Mechanical Components Spare Parts List / 4 3.5, 17
- Mechanical Components Spare Parts List / 8 2.5, 18
- system components / 2 3.5, 22
- system components / 4 3.5, 24, 26
- system components / 8 2.5, 28

F

front panel components, 96

H

hard drive

- installing, 50
- removing, 49, 51, 52

hard drive blank

- removing, 50

Hard drive LED indicators, 106

hardware configuration

- BBWC, 86
- dedicated management port, 82
- hard drives, 47
- memory, 68
- optical disk drive, 45
- PCI expansion card, 72

- power supply unit, 90
- processor, 62
- references, 33
- system battery, 84
- system fan, 94
- top cover, 37

hardware configuration tools, 33

hardware specifications

- I/O ports, 121
- LAN controller, 121
- memory, 121
- processor socket, 121
- processor support, 121
- status LED indicators, 122
- thermal solution, 122

Hardware Specifications, 121

- chipset, 121
- default media storage, 121
- Hardware monitoring device, 121
- I/O subsystem, 121
- optical media storage, 121

hazardous conditions. *See* symbols on equipment

hazardous energy circuits

- symbol, 35

heat sink

- installing, 66
- removing, 63

hot surface

- symbol, 35
- warning, 35

hot-plug PSU

- reinstalling, 91
- removing, 90

HP

- authorized reseller, 31
- contact information, 31
- technical support, 31
- technical support requirements, 31

I

improper airflow

- caution, 35

L

LAN controller, 121

LED indicator

- system board LED, 108

LED indicators

- LAN, 107
- optical disk drive activity, 105

M

mechanical components / 2 3.5, 16

mechanical components / 4 3.5, 17

mechanical components / 8 2.5, 18

memory module

- installing, 70
- removing, 69

memory modules

- spare part number, 22, 24, 26, 28

N

non hot plug hard drive disk

- installing, 53

non-hot-plug PSU

- reinstalling, 92
- removing, 92

O

onboard controllers

- LAN, 121
- storage controller, 121

optical carrier

- installing, 47

optical disk drive

- activity indicator, 105

P

PCI cage

- reinstalling, 80
- removing, 75

PCI expansion board

- installing, 79

PCI riser card expansion slot, 73

PCIe riser card

- installing**, 77
- removing, 75

PCIe/PCI-X riser cards

- installing, 75

physical dimensions, 123

- server, 123
- system board, 123

power supply unit. *See* PSU

Power-On Self Test

- POST error indicators, 117

- POST related troubleshooting, 119
- recoverable POST errors, 118
- SETSYS utility, 119
- processor
 - applying thermal grease compound, 65
 - installing, 66
 - removing, 64
- processor socket
 - specification, 121
- processors
 - spare part number, 22, 24, 27, 28
- PSU
 - replacement warnings, 91

R

- rear panel components, 100

S

- SAS/SATA hard drives with carriers
 - spare part number, 23, 25, 27, 29
- server dimensions
 - rack, 123
- server warnings and cautions, 35
- Setup Utility menu bar
 - advanced menu, 112
 - boot menu, 114
 - exit menu, 116
 - security menu, 115
- specifications
 - physical and operating, 121
- storage controller, 121
- symbols on equipment, 35
- system battery
 - replacing, 85

- system board
 - components, 102
 - dimensions, 123
 - LED, 108
 - platform, 123
 - reinstalling, 88
 - spare part number, 22, 24, 26, 28
- system components / 2 3.5, 22
- system components / 4 3.5, 24, 26
- system components / 8 2.5, 28
- system cover
 - top cover, 37
- system fan
 - installing, 95
 - removing, 94
- system fans
 - spare part number, 23, 25, 27, 29
- system LEDs. See status LEDs
- system structure
 - front panel, 96
 - rear panel, 100
 - system board, 102

T

- thermal solution, 122
- top cover
 - reinstalling, 37
 - removing, 37

W

- warnings
 - battery replacement, 85
 - PSU replacement, 91
- warranty, 5